General Disclaimer

One or more of the Following Statements may affect this Document

- This document has been reproduced from the best copy furnished by the organizational source. It is being released in the interest of making available as much information as possible.
- This document may contain data, which exceeds the sheet parameters. It was furnished in this condition by the organizational source and is the best copy available.
- This document may contain tone-on-tone or color graphs, charts and/or pictures, which have been reproduced in black and white.
- This document is paginated as submitted by the original source.
- Portions of this document are not fully legible due to the historical nature of some
 of the material. However, it is the best reproduction available from the original
 submission.

Produced by the NASA Center for Aerospace Information (CASI)

X-562-68-388

PREPRINT

63389

SUPPORT SOFTWARE FOR THE SPACE ELECTRONICS BRANCH ON-BOARD PROCESSOR

(CODE)

(NASA CR OR TMX OR AD NUMBER)

(THRU)

(CODE)

(CATEGORY)

NOVEMBER 1968



GODDARD SPACE FLIGHT CENTER

GREENBELT, MARYLAND



SUPPORT SOFTWARE

FOR THE

SPACE ELECTRONICS BRANCH ON-BOARD PROCESSOR

A. Merwarth T. Taylor

Space Electronics Branch Information Processing Division

November 1968

GODDARD SPACE FLIGHT CENTER Greenbelt, Maryland

PRECEDING PAGE BLANK NOT FILMED.

SUPPORT SOFTWARE FOR THE SPACE

ELECTRONICS BRANCH ON-BOARD PROCESSOR

A. Merwarth
T. Taylor
Space Electronics Branch
Information Processing Division

ABSTRACT

This paper describes the support software package which exists for the On-Board Processor (OBP) being developed by the Space Electronics Branch, GSFC.

PRECEDING PAGE BLANK NOT FILMED.

		Pag
INTRODUC	CTION	1
SUPPORT	SOFTWARE SYSTEM	1
Asser	mbler	2
	Registers Instruction Set	3 4
Asser	mbler Directives	20
	Control of Storage Allocation	21 25 29 30
Relo	catable Loader	30
Simu	lator	31
	Interrupt Simulation	31 31 35 35 35
	rol CardsLator Control Cards	42 47
	Inputting Data Stopping and/or Restarting	53 53
	nosticsary	54 54
PROGRAM	MING NOTES	56
Inter Scale	t/Output rruptse Register	57 60 60 61
Store	age Limit Register	63 63

PRECEDING PAGE BLANK NOT FILMED.

Figure

ILLUSTRATIONS

Page

1	COMPUTER LISTING OF MAIN PROGRAM (COMBINATIONS) AND SUBROUTINE (FACTORIAL)	, 32
2	CORE IMAGE DIAGRAM OF AUTOMATIC CODE AND DATA RELOCATION	, 33
3	COMPUTER PRINTOUT OF DECIMAL DUMP	. 36
4	COMPUTER PRINTOUT OF OCTAL DUMP	. 37
5	COMPUTER PRINTOUT OF DECIMAL TRACE	. 39
6	COMPUTER PRINTOUT OF OCTAL TRACE	. 40
7	DECK SETUP FOR EDIT AND AUGMENT	. 44
	TABLES	
Table	CENTRAL PROCESSOR UNIT FUNCTIONAL REGISTERS	• 3

(M) INPUT/OUTPUT FORMAT.....

INTRODUCTION

The support software package described in this paper was developed for use with the On-Board Processor (OBP) - an 18 bit, stored program digital computer designed for spacecraft application. For a complete description of the OBP refer to document X-562-68-387, "A GENERAL PURPOSE ON-BOARD PROCESSOR FOR SPACECRAFT APPLICATION." dated October 1968.

The guiding philosophy for software development was to make a powerful hardware system easy to use with the aid of software. To this end a support software system has been developed which allows a programmer to use either existing English verbs, or define his own set of mnemonics. Other objectives in the development of the software system were to allow independent programming by OBP users at different locations, and by its simplicity allow efficient user program construction and debugging.

SUPPORT SOFTWARE SYSTEM

The support software system consists of an assembler, a relocatable loader, a simulator, a library of math subroutines, and a set of CPU diagnostics. The system was written in Fortran as a step towards machine independence so that OBP programs could be developed at different locations.

At present, the system has been run and checked out on SDS 920 and UNIVAC 1108 computers at GSFC, and on a GE 635 computer at General Electric Company, Valley Forge, Pennsylvania. At GSFC a special interface unit between a SDS 920 computer and an engineering model of the OBP allows object programs to be loaded into OBP memory and executed. It also permits the transfer of data between OBP memory and the SDS 920 I/O devices.

The support software system is contained on one magnetic tape. The system requires a card reader, a CPU, a line printer, and three magnetic tape drives (one for the system and two scratch). The system which was written for the SDS 920 computer contains 21 links due to core memory limitations.

The OBP assembler accepts punched cards as input, assembles program segments into relocatable binary code and data and writes the program segments on a magnetic tape. The binary segments can then be selectively loaded onto a complete image of OBP memory and written on tape. The memory image tape can be used to either load the OBP memory or to serve as input to a functional OBP simulator, a unit of the support software system.

A call to a subprogram not found in any assembled program segment will result in an automatic library search. The library now contains the following math functions: square root, sine, cosine, arc tangent, exponential, and logarithm.

Assembler

A program to be assembled must be on punched cards and must be preceded by an assemble control card. The format of the assemble control card with an explanation of the various options is covered in the section on control cards.

In order to gain a degree of self-documentation and make the generation of symbolic code as simple as possible, the OBP assembler has the following unique features:

- English language structure a set of verb phrases have been defined rather than the usual set of three letter mnemonics.
- Flexibility if a particular programmer prefers a certain set of mnemonics, this set may be "augmented" into the assembler very easily.
- Free form there are no restrictions on where specific fields are aligned on the input cards. More than one machine instruction may be on one card, and text may be freely continued from one card to the next with no special indication.
- Punctuation free use of standard English punctuation is permitted since the punctuation characters are treated as blanks. Comments within parentheses are ignored and are not restricted to one card in length.

The above features make possible the following two ways of writing OBP code:

EXAMPLE 1

Let X times X yield X squared. Let Y times Y plus X squared transformed by square root yield Norm. If Norm is not greater than 1 then go to compute inside the unit circle; otherwise....

EXAMPLE 2

LDA	X
MUL	X
STA	X2
LDA	Y
MUL	Y
ADD	X 2
BRM	SQRT
STA	NORM
IET	1
BRC	COMP

In EXAMPLE 1 each line represents an input card, and in EXAMPLE 2 the mnemonics which have been added to the GSFC facility are used. In both cases, it is assumed that a scale register in the OBP had been set to 17 resulting in an automatic shift following each multiply.

As seen from the above examples, the assembler recognized LET as a symbol for the operation "load accumulator," the word TIMES as a symbol for the operation "multiply the operand by the accumulator, leaving the result after shifting in the accumulator," etc. Another feature of the assembler which applies independently of mnemonics is that the operand symbol may be of any length, because the assembler treats everything between two consecutively recognized operation symbols as an operand symbol.

Registers - Registers which can be affected by program execution are listed in Table 1.

TABLE 1

Central Processor Unit Functional Registers

Register	Symbol	Length (bits)	Function
Accumulator	A	18	Used for operand storage.
Extended Accumulator	EA	18	Holds least significant half of a double length operand in multiply/divide operations.

TABLE 1 (Continued)

Central Processor Unit Functional Registers

Register	Symbol	Length (bits)	Function Controls where writing into memory is permitted		
Storage limit	SL	18			
Subscript	ss	18	Added to address to form effective address if subscript bit in instruction word is set.		
Scale	SC	6	Represents location of binary point for numbers.		
Page	P	4	Appended to high order of 12 bit address field to form 16 bit address.		
Carry	C	1	Stores a carry out of bit 17 of the parallel adder.		
Decision	D		Is conditionally set or reset when executing test and conditional transfer instructions.		
OR/AND	O/A		Determines whether the result of tests are to be ORed or ANDed into the D register.		
Overflow	ov	1	Stores the overflow condition.		

Instruction Set - The OBP has 50 instructions, 30 of which require a memory access. The other 20 instructions have a minor operation code in the operand field of the instruction word. The formats are as follows:

MEMORY ACCESS

NON-MEMORY ACCESS

With 12 bits of address available, 4,096 memory words are directly addressable. A memory size as large as 65,536 words requires a 4-bit page register which can be loaded and stored under program control and which is appended as four high-order bits to the 12-bit address field to form a full 16-bit address. If the subscript bit is set the low order 16-bits of the subscript register are added to the address to form an effective address, and the execution time is increased by 2.5 usec. The thirty instructions which require a memory access may be indexed. Indexing is specified by using either SUBSCRIPTED, or XED between the verb or mnemonic and the noun or memory location. For example, either LET SUBSCRIPTED NUMBER or LDA XED NUMBER will result in a load accumulator instruction with bit 13 set so that the subscript register will be added to the address field at execution time to form the effective address.

In the following description, the English verb and assembly language mnemonic which exist in the GSFC 920 assembler are shown.

LET noun, IF noun
LDA noun

The content of storage at the effective address is placed in the accumulator.
Registers altered: accumulator
Timing: 6.25 usec

LET LOCATION OF noun LDL noun

40 noun

The effective address is placed in the accumulator. Registers altered: accumulator Timing: 5.0 usec

YIELD noun
STA noun

60 n o u n

The content of the accumulator is stored at the effective address unless that address is protected by the storage limit registers. If storage is protected, no write into memory occurs.

Registers altered: none

Registers altered: none Timing: 7.5 usec

SET EXTENSION WITH noun LDE noun

52noun

The content of storage at the effective address is placed in the extended accumulator.

Registers altered: Extended accumulator

Timing: 6.25 usec

SAVE EXTENSION IN <u>noun</u> STE <u>noun</u>

10noun

The content of the extended accumulator is stored at the effective address unless that address is protected by the storage limit registers. If storage is protected, no write into memory occurs.

Registers altered: none
Timing: 7.5 usec

PLUS <u>noun</u> ADD noun 0 4 n o u n

The content of storage at the effective address is added to the content of the accumulator and the sum is retained in the accumulator. If a carry occurs at the input of the 18th stage of the two's complement adder, then the carry register is set to one. Otherwise, the carry register is reset to zero. Overflow can occur when two numbers of the same sign are added. Overflow causes the 18th bit of the sum to remain in the sign position and the overflow register to be set to one.

Register altered: Accumulator

Carry register

Overflow register (conditionally)

Timing: 6.25 usec

44noun

TIMES noun
MUL noun

The content of storage at the effective address is multiplied by the content of the accumulator. The high-order 17 bits and sign of the product are retained in the accumulator. The low-order 17 bits and sign of the product are retained in the extended accumulator. The double length product is automatically scaled by arithmetically shifting the accumulator and the 17 bits of the product in the extended accumulator the number of bit positions indicated by the content of the scale register. The sign bit of the extended accumulator is not shifted. If the content of the scale register is negative, then the shift is right a and the content of the sign fills positions vacated on the left so that no overflow is possible. If the content of the scale register is positive, then the shift is to the left, with zeros filling positions vacated on the right. The overflow register is set to one if the sign bit of the accumulator is changed during the shift.

Registers altered: Accumulator

Extended accumulator Overflow register (conditionally)

Timing: If content of scale register 17, 31.25 + (# of 1's in multiplier + /scale/) x 1.25 usec

If content of scale register 17, 31.25 + (# of 1's in multiplier + scale -15) x 1.25 usec

OVER noun, DIVIDED BY noun DIV noun

6 4 n o u n

The content of the accumulator and extended accumulator are automatically scaled by shifting them the number of bit positions indicated by the content of the scale regis-The sign of the extended accumulator is ignored and not shifted. If the content of the scale register is negative, then the shift is left with zeros filling positions vacated on the right and if the sign bit of the accumulator is changed during the shift, the overflow register is set to one. If the content of the scale register is positive, then the shift is to the right and the content of the sign fills positions vacated on the left so that overflow is impossible. The scaled accumulator and extended accumulator form the dividend that is divided by the content of storage at the effective address. The overflow register is set if the content of the accumulator is greater than or equal to the content of storage. The signed quotient is retained in the accumulator and the signed remainder is retained in the extended accumulator.

The remainder has the same sign as the dividend and has a magnitude less than the divisor.

Registers altered: Accumulator

Extended accumulator

Overflow register (conditionally)

Timing: If content of scale register 17, 87.5 + /scale/

x 1.25 usec

If content of scale register 17, 87.5 + (scale

-15) x 1.25 usec

In either case, add 7.50 usec if divident 0

PLUS CARRY ADC 000006

The content of the carry register is added to the content of the accumulator and the sum is retained in the accumulator. If a carry occurs at the input of the 18th bit of the two's complement adder, then the carry register is set to one. Otherwise, the carry register is reset to zero. Overflow can occur and will cause the 18th bit of the sum to remain in the sign position and the overflow register to be set to one.

Registers altered: Accumulator

Carry register

Overflow register (conditionally)

Timing: 5.0 usec

NEGATED NEG

The content of the accumulator is replaced by its two's complement. Negating all zeros yields a result of zero and sets the carry register to one. Negating the number that has zeros in all bit positions except the sign yields the same number as a result and sets both the carry register and the overflow register to one. Other than these two special cases, the carry register to reset to zero.

Registers altered: Accumulator

Carry register
Overflow register (conditionally)

Timing: 5.0 usec

ANDED WITH noun ETR noun

30 n o u n

The content of storage at the effective address is anded with the content of the accumulator. The result is retained in the accumulator. The 18 bits of the result are computed independently with a one occurring in a bit position of the

result only if the accumulator and storage both contained a one in that bit position.
Registers altered: Accumulator
Timing: 6.25 usec

ORED WITH noun MRG noun

50noun

The content of storage at the effective address is ORed with the content of the accumulator. The result is retained in the accumulator. The 18 bits of the result are computed independently with a one occurring in a bit position of the result if either the accumulator or storage contained a one in that bit position. Registers altered: Accumulator Timing: 6.25 usec

EORED WITH noun, EXCLUSIVELY ORED WITH noun EOR noun

7 0 n o u n

The content of storage at the effective address is exclusively ORed with the content of the accumulator. The result is retained in the accumulator. The 18 bits of the result are computed independently with a one occurring in a bit position of the result if either the accumulator or storage, but not both, contain a one in that bit position. Registers altered: Accumulator Timing: 6.25 usec

COMPLEMENTED CMP

0 0 0 0 1 0

The content of the accumulator is complemented and the result is retained in the accumulator. The 18 bits of the result are computed independently with a one occurring in a bit position of the result only if the accumulator contained a zero in that position.

Registers altered: Accumulator

Timing: 5.0 usec

SHIFTED BY noun
SHF noun

14 n o u n

The low-order 6 bits of the content of storage at the effective address is used as a two's complement shift count. If the count is negative, then the accumulator is shifted right the number of positions specified by the count, with the content of the accumulator sign replacing vacated positions on the left. If the count is positive,

then the accumulator is shifted left the number of positions specified by the count with zeros filling vacated positions on the right. The overflow register is set to one if the sign bit of the Accumulator is changed during the shift.

Registers altered: Accumulator

Overflow register (conditionally)

Timing: 6.25 usec + 1.25 usec per position shifted

DOUBLE SHIFTED BY noun DSH noun.

3 6 n o u n

The low-order 6 bits of the content of storage at the effective address is used as a two's complement shift count. The accumulator and the extended accumulator are shifted together. The extended accumulator is to the right of the accumulator and its sign bit is not shifted. If the count is negative, then the accumulators are shifted right the number of positions specified by the count with the content of the accumulator sign replacing vacated positions on the left. If the count is positive, then the accumulators are shifted left the number of positions specified by the count with zeros filling vacated positions on the right. The overflow register is set to one if the sign bit of the accumulator is changed during the shift.

Registers altered: Accumulator

Overflow register (conditionally)

Timing: 6.25 usec + 1.25 usec per position shifted

CYCLED BY noun
CYC noun

34 n o u n

The low-order 6 bits of the content of storage at the effective address is used as a two's complement shift count. If the count is negative, then the content of the accumulator is shifted cyclically right the number of positions specified by the count, with bits leaving the low-order position entering the sign position. If the count is positive, then the content of the accumulator is shifted left the number of positions specified by the count with bits leaving the sign position entering the low-order position.

Timing: 6.25 usec + 1.25 usec per position shifted

DOUBLE CYCLED BY noun DCY noun

56 noun

The low-order 6 bits of the content of storage at the effective address is used as a two's complement shift count. If the count is negative, then the content of the accumulator and extended accumulator is shifted cyclically right the number of positions specified by the count with bits leaving the low-order position of the extended accumulator entering the sign of the accumulator and bits leaving the low-order position of the accumulator entering the sign of the extended accumulator. If the count is positive, then the content of the accumulator and extended accumulator is shifted left the number of positions specified by the count with bits leaving the sign of the entended accumulator entering the low-order position of the accumulator and bits leaving the sign position of the accumulator entering the low-order position of the extended accumulator.

Registers altered: Accumulator

Extended accumulator

Timing: 6.25 usec + 1.25 usec per position shifted

NORMALIZED NORM 000014

The content of the accumulator and extended accumulator is shifted left until the 17th and 18th bits of the accumulator are different. The sign bit of the extended accumulator is not shifted. Bits leaving the 17th bit of the extended accumulator enter the low-order position of the accumulator. Zeros fill the positions vacated on the right. A count of the number of positions shifted is retained as a 6-bit positive number in the scale register. If the content of the accumulator and positions 1 through 17 of the extended accumulator are zero, then the scale register is set to zero.

Registers altered: Accumulator

Extended accumulator

Scale register

Timing: 5.0 usec + 1.25 usec per position shifted or 26.25 usec if accumulator and extended accumulator are both zero.

CLOSE EXTENSION WITH DECISION

0 0 0 0 1 3

The content of the accumulator and extended accumulator is shifted left one position. The sign of the extended

accumulator is not shifted and the vacated, low-order position of the extended accumulator is filled with the content of the decision register. The overflow register is not altered.

Registers altered: Accumulator

Extended accumulator

Timing: 3.75 usec

TRANSPOSED FLP

0 0 0 0 2 2

The contents of the accumulator are reversed. The (19-n)th and nth bits are exchanged for n=1,2,...9.
Registers altered: Accumulator
Timing: 3.75 usec

USE SUBSCRIPT noun LDX noun

54 noun

The content of storage at the effective address is placed in the subscript register.
Registers altered: Subscript register
Timing: 5.0 usec

SAVE SUBSCRIPT IN noun STX noun

7 4 n o u n

The content of the subscript register is stored at the effective address unless that address is protected by the storage limit registers. If storage is protected, no write into memory occurs.

Registers altered: none
Timing: 7.5 usec

STEP SUBSCRIPT BY noun ADX noun

0 2 n o u n

The content of storage at the effective address is added to the content of the subscript register. The 18-bit result of the two's complement addition is retained in the subscript register.

Registers altered: Subscript register Timing: 6.25 usec

THEN GO TO noun BRC noun

 $2 \mid n \circ u \mid n$

If the content of the decision register is zero, then the next sequential instruction is executed. If the content of the decision register is one, then the content of storage at the effective address is placed in the instruction counter and execution proceeds from the address specified by the instruction counter.

The decision register and OR/AND register are reset to

Decision register Registers altered:

OR/AND register

Timing: 5.0 usec

GO TO noun, RETURN FROM noun BRU noun

62 noun

The content of storage at the effective address is placed in the instruction counter and execution proceeds from the address specified by the instruction counter. Registers altered: none Timing: 5.0 usec

TRANSFORMED BY noun, PERFORM noun BRM noun

06 noun

The content of the instruction counter plus one is stored at the effective address unless that address is protected by the storage limit registers. If storage is protected, no write into memory occurs. The content of one location greater than the effective address is placed in the instruction counter and execution proceeds from the address specified by the instruction counter. Registers altered: none

Timing: 10.0 usec

AND

0 0 0 0 1 1

The OR/AND register is set to one. Registers altered: OR/AND register Timing: 3.75 usec

OR

0 0 0 0 1 5

The OR/AND register is set to zero. Registers altered: OR/AND register Timing: 3.75 usec

IS LESS THAN <u>noun</u> ILT noun

26 noun

If the content of the accumulator is less than the content of storage at the effective address, then the test condition is set to one. Otherwise, it is zero. The OR/AND register being zero specifies that the test condition is to be ORed with the content of the decision register and the result is to be retained in the decision register. The OR/AND register being one specifies that the test condition is to be ANDed with the content of the decision register and the result is to be retained in the decision register and the result is to be retained in the decision register.

Registers altered: Decision register

Timing: 6.25 usec

IS EQUAL TO noun IET noun

日本の本では、日本のは、日本のは、日本のでは

46 n o u n

If the content of the accumulator is equal to the content of storage at the effective address then the test condition is set to one. Otherwise it is zero. The OR/AND register being zero specifies the test condition is to be ORed with the content of the decision register and the result is to be retained in the decision register. The OR/AND register being one specifies the test condition is to be ANDed with the content of the decision register and the result to be retained in the decision register. Registers altered: Decision register Timing: 6.25 usec

IS GREATER THAN noun IGT noun

6 6 n o u n

If the content of the accumulator is greater than the content of storage at the effective address the test condition is set to one. Otherwise, it is zero. The OR/AND register being zero specifies that the test condition is to be ORed with the content of the decision register and the result is to be retained in the decision register. The OR/AND register being one specifies that the test condition is to be ANDed with the content of the decision register and the result is to be retained in the

decision register.
Registers altered: Decision register
Timing: 6.25 usec

IF OVERFLOW TOV

0 0 0 0 0 1

If the content of the overflow register is one, then the test condition is set to one. Otherwise, it is zero. The overflow register is reset to zero. The OR/AND register being zero specifies that the test condition is to be ORed with the content of the decision register and the result is to be retained in the decision register. The OR/AND register being one specifies that the test condition is to be ANDed with the content of the decision register and the result is to be retained in the decision register. Registers altered: Decision register

Overflow register

Timing: 3.75 usec

Truttig. 3:73 us

IF PARITY ODD

0 0 0 0 0 5

If the number of ones in the 18-bit accumulator is odd, then the test condition is set to one. Otherwise, it is zero. The OR/AND register being zero specifies that the test condition is to be ORed with the content of the decision register and the result is to be retained in the decision register. The OR/AND register being one specifies that the test condition is to be ANDed with the content of the decision register and the result is to be retained in the decision register.

Registers altered: Decision register Timing: 26.25 usec

IS POSITIVE IGZ

0 0 0 0 0 3

If the sign position, bit 18, of the accumulator contains a zero, then the test condition is set to one. Otherwise, it is zero. The OR/AND register being zero specifies that the test condition is to be ORed with the content of the decision register and the result is to be retained in the decision register. The OR/AND register being one specifies that the test condition is to be ANDed with the content of the decision register and the result is to be retained in the decision register.

Registers altered: Decision register Timing: 3.75 usec

IS EQUAL TO ZERO LEZ

0 0 0 0 2 1

If the value of the contents of the accumulator is equal to zero, then the test condition is set to one. Otherwise, it is zero. The OR/AND register being zero specifies that the test condition is to be ORed with the content of the decision register and the result is to be retained in the decision register. The OR/AND register being one specifies that the test condition is to be ANDed with the content of the decision register and the result is to be retained in the decision register.

Registers altered: Decision register Timing: 3.75 usec

IF SUBSCRIPT IS NOT GREATER THAN <u>noun</u> XNGT <u>noun</u>

2 2 n o u n

If the content of the subscript register is less than or equal to the content of storage at the effective address, then the test condition is set to one. Otherwise, it is zero. The OR/AND register being zero specifies that the test condition is to be ORed with the content of the decision register and the result is to be retained in the decision register. The OR/AND register being one specifies that the test condition is to be ANDed with the content of the decision register and the result is to be retained in the decision register.

Registers altered: Decision register Timing: 6.25 usec

8.75 usec if subscripted

IS FALSE

0 0 0 0 1 7

The Decision register is complemented Registers altered: Decision register Timing: 3.75 usec

PASS NOP 0 0 0 0 0 2

No operation is performed other than the automatic incrementing of the instruction counter. Registers altered: none Timing: 3.75 usec

HALT HLT 000000

The processor stops indefinitely. An initiate signal must be supplied from an external source to start the processor.

Registers altered: none
Timing: none

EXECUTE noun

12 noun

The content of storage at the effective address is used as the address of the instruction to be executed. The instruction counter is incremented by one unless it is changed by the execution of a transfer-type instruction. If the machine attempts to execute an EXECUTE noun, the program proceeds with no operation being performed.

Registers altered: those associated with the instruction executed.

Timing: 5.0 usec + executed instruction timing.

SET SCALE WITH noun LDS noun

3 2 n o u n

The low-order 6 bits of the content of storage at the effective address is placed in the scale register. Registers altered: Scale register Timing: 5.0 usec

LET SCALE

000020

The content of the scale register is placed in the loworder 6 bits of the accumulator. The high-order 12 bits of the accumulator are set to zero. Registers altered: Accumulator Timing: 3.75 usec

SET PAGE

0 0 0 0 1 2

The content of bits 13 through 16 of the accumulator are placed in the page register.
Registers altered: Page register
Timing: 3.75 usec.

RESET OVERFLOW ROV

000007

The content of the overflow register is set to zero. Registers altered: Overflow register Timing: 3.75 usec

RESET DECISION RED

0 0 0 0 2 3

The contents of the decision register is set to zero. Registers altered: Decision register Timing: 3.75 usec

EXIT

0 0 0 0 1 6

This instruction initiates interrupt number 16 and uses locations octal 200 through 207. Upon completion, execution proceeds normally using the new value in the instruction counter.

Registers altered:

Limit register

Interrupt priority register

Page register
OR/AND register
Overflow register
Carry register
Decision register
Scale register

Timing: 35.0 usec

RESUME FROM noun
TIN noun

7 2 n o u n

The content of storage at the effective address is used as the starting address of an interrupt storage area. This instruction reloads the registers that were saved at the occurrence of an interrupt. Upon 'mpletion, execution proceeds normally using the new value in the instruction counter.

Registers altered: Limit Register

Interrupt priority register

Page register
OR/AND register
Overflow register
Carry register
Decision register
Scale register

Timing: 21.25 usec

CONNECT TO noun
IO noun

16 noun

The content of storage at the effective address is sent to the I/O unit as a command. This word must have a zero in bits 17 and 18 to denote the establishment of a cycle steal channel. Bits 1 through 16 specify the data channel and block length. The content of the accumulator is stored at location seven. The content of location seven is then output as a starting memory address to the I/O unit. Registers altered: none Timing: 11.25 usec

LET FUNCTION TO noun IO noun

16 noun

The content of storage at the effective address is sent to the I/O units as a command. This word must have a zero in bit 18 and a one in bit 17 to denote that bits 1 through 16 are a function code.

Registers altered: none
Timing: 5.0 usec

OUTPUT TO noun

IO noun

16 noun

The content of storage at the effective address is sent to the I/O unit as a command. This word must have a one in bit 18 and a zero in bit 17. Bits 1 through 16 denote the data channel for an output device. The content of the accumulator is stored at location seven. The content of location seven is then output as data to the I/O unit. Registers altered: none Timing: 11.25 usec

LET INPUT FROM noun IO noun

16 noun

The content of storage at the effective address is sent to the I/O unit as a command. This word must have a one in bits 17 and 18. Bits 1 through 16 denote the data channel for an input device. The I/O unit stores one word of data at location seven. The content of location seven is then placed in the accumulator Registers altered: Accumulator Timing: 11.25 usec

Assembler Directives

Assembler directives are used to pass information to the assembler concerning a particular program to be assembled. The assembler directives are loaded in with the source program and enjoy the same freedom from fixed card format as does the symbolic program statements. These directives have affect only for the program with which they are assembled and their affect begins when they are encountered during the assembly process. For convenience, the assembler directives can be delineated into four categories according to their usage or function in the program. These categories are:

ACCTON		7. 0	CATTONE				
·		-					
ALLOCATI			LOCATION	s FOR			
END OF T	HIS PROGI	RAM SEGM	ENT				
b. Data	Word Car	neration					
PREDEFIN	<u> </u>		AS THE	VALUE	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	
PRESET_		VALUES O	۶ <u></u> _	то тн	E CONS	CANTS	
THE RADI	X FOR NU	MBERS IS	DECIMAL				
THE RADI	X FOR NUM	MBERS IS	OCTAL				
THE SCAI	E FACTOR	FOR NUM	BERS IS				
	E FOR NU		-				
		OCTAL					
		DECIMAL_					
		SCALED			<u> </u>		

DEFINING FOR EXTERNAL USE

SUBSCRIP	TED	

d. Connectives

- LET IT
- IF IT
- BE
- OTHERWISE
- AND ALSO

Control of Storage Allocation -

START THE FOLLOWING INSTRUCTIONS AT LOCATION number START THE FOLLOWING INSTRUCTIONS AT LOCATION noun

This directive allows the user to alter the assembler's automatic assignment of storage by specifying the origin of the following group of instructions. This allows specific arrangements of various sequences of instructions both in relation to themselves and to the memory capacity available to the particular program. The origin is the location in memory from which the sequence of instructions will be executed. If number is used, then the origin will be the absolute memory address equal to the number specified. If noun is used, then the origin will be absolute provided the noun in question has been previsouly assigned a numeric value. Otherwise, the origin is subject to relocation by the loader. Once this directive has been encountered, the verbs are assembled as having addresses beginning with the value of noun or number and increasing by one for each succeeding instruction until either an END OF THIS PROGRAM SEGMENT or another START THE FOLLOWING INSTRUCTIONS AT LOCATION is encountered.

Restrictions:

number should be positive and smaller than the memory size. It is the user's responsibility to be sure that the same absolute locations are used only once.

noun should have been previously used with the directive DEFINING noun or with the directive ASSIGN noun TO LOCATION number. The storage allocation of relocatable sequences of instructions and relocatable sequences of data words in independent during assembly and loading. No distinction

is made during loading between instructions and data words with absolute addresses.

Examples:

START THE FOLLOWING INSTRUCTIONS AT LOCATION 4095
START THE FOLLOWING INSTRUCTIONS AT LOCATION OCTAL 3777
START THE FOLLOWING INSTRUCTIONS AT LOCATION LABEL 2

START THE FOLLOWING DATA AT LOCATION number START THE FOLLOWING DATA AT LOCATION noun

This directive allows the user to alter the assembler's automatic assignment of storage by specifying the origin of the succeeding data addresses. This allows specific arrangements of various sequences of data words or data addresses in relation to themselves and to the memory capacity available to the particular program. The origin is the location in memory where data words or data addresses will begin at execution time. If number is used, then the origin will be the absolute memory address equal to the number specified. If noun is used, then the origin will be absolute provided the noun in question has been previously assigned a numeric value. Otherwise the origin is subject to relocation by the loader. Once this directive has been encountered, data words generated by PREDEFINE and PRESET and nouns specified in ALLOCATE and ASSIGN noun will be assigned data addresses beginning with the value of noun or number and increased by one for each succeeding address until either an END OF THIS PROGRAM SEGMENT or another START THE FOLLOWING DATA AT LOCATION is encountered.

Restrictions:

number must be positive and smaller than 4096. The relocatable data origin of the support software loader may be altered by the user to cause relocatable data to be loaded anywhere in the On-Board Processor's memory.

noun should have been previously used in an ASSIGN, ALLOCATED, PREDEFINE, or PRESET assembler directive.

The storage allocation of relocatable sequences of instructions and relocatable sequence of data words is independent during assembly and loading. No distinction is made during loading between instructions and data words with absolute addresses.

Certain data addresses are not assigned until the END OF THIS PROGRAM SEGMENT directive is encountered.

These include: the data address for constants used as the object of machine verbs; the data address of the indirect address for the noun used as the object of GO TO, THEN GO TO, TRANSFORMED BY, PERFORM, and RETURN FROM machine verbs; the data address of nouns used as the objects of machine verbs that did not appear in ASSIGN, ALLOCATE, PREDEFINE, or PRESET directives.

Examples:

START THE FOLLOWING DATA AT LOCATION 3999 START THE FOLLOWING DATA AT LOCATION OCTAL 100 START THE FOLLOWING DATA AT LOCATION MATRIX

ASSIGN noun 1 TO LOCATION number
ASSIGN noun 1 TO LOCATION noun 2

This assembler directive provides a method of assigning nouns which represent data to specific memory locations. It is not necessary to assign all nouns storage locations because the assembler will automatically assign one location for each noun that is used only as the object of a machine verb. The first case causes noun 1 to be assigned the next available data location and causes the data location counter to be incremented by one. The second case causes noun 1 to be assigned the absolute memory address specified by <u>number</u>. The data location counter is not changed. The third case causes noun 1 to be assigned to this same memory address as noun 2. If noun 2 has previously been assigned an address then the data location counter is not incremented. If noun 2 is unassigned when this directive is encountered, then both noun 1 and noun 2 are assigned the next available data location and the data location counter is incremented by one.

Restrictions:

Multiple assignment of noun 1 is allowed but only the last assignment is used as the address to be placed in machine instructions.

number must be positive and less than 4096. When the next available data location is used, the noun is relocatable or absolute according to the most recent data origin that has been established.

Neither noun 1 nor noun 2 may be used as the object of GO TO, THEN GO TO, TRANS-FORMED BY, PERFORM or RETURN FROM machine verbs. Nouns for these verbs refer indirectly to a position in the instruction sequence and must be defined by the DEFINING or DEFINING FOR EXTERNAL USE assembler directives.

Examples:

ASSIGN ALPHA

ASSIGN L TO LOCATION LONGITUDE

ASSIGN COMMON DATA TO LOCATION OCTAL 7000

ALLOCATE number LOCATIONS FOR noun

This directive is used to reserve data storage for a vector or array whose name is designated by <u>noun</u>. The number of locations reserved for the <u>noun</u> vector is specified by <u>number</u>. The <u>noun</u> is assigned the next available data location when this directive is encountered. The data location counter is then incremented by <u>number</u>. In a program, <u>noun</u> will usually appear preceded by SUBSCRIPTED. During execution the subscript register would typically contain a value between 0 and number -1.

Restrictions:

noun must not have appeared previsouly in an ASSIGN, PRESET, or PREDEFINE assembler directive. However, noun may appear in a subsequent PRESET or PREDEFINE assembler directive and retain the address assigned when allocated. If noun appears in a subsequent ASSIGN statement, its address will be changed.

Examples:

ALLOCATE 100 LOCATIONS FOR TEN BY TEN MATRIX
ALLOCATE OCTAL 77 LOCATIONS FOR TABLE

END OF THIS PROGRAM SEGMENT

This directive is used to inform the assembler of the end of a program. Upon encountering this directive, each machine instruction has been assigned either a relocatable or absolute instruction address. After this directive is encountered, nouns that have not appeared in ASSIGN, PREDEFINE, PRESET, or ALLOCATE assembler directives and constants used with machine verbs will be assigned data storage.

Restrictions: This directive must appear physically as the last sentence of input to the assembler. The next input card is expected to be a control card with a semicolon in column one.

Data Word Generation -

PREDEFINE noun AS THE VALUE literal

This assembler directive may be used to initialize a data location to a fixed constant. If noun has previously been assigned a data address via a PREDEFINE, PRESET, ALLOCATE, or ASSIGN directive, then the <u>literal</u> will be loaded into memory at the assigned address. Otherwise, <u>noun</u> is assigned the next available data location and the data location counter is incremented by one. The <u>literal</u> will be loaded into memory at the assigned address reserved for <u>noun</u>. The value of noun may be modified during execution, by machine instructions that stored into memory.

Restrictions:

The memory address where the <u>literal</u> is initialized is not changed if <u>noun</u> is subsequently assigned another data location. If the same memory location is initialized more than once, then the last <u>literal</u> value will be in memory when the program is executed.

The <u>literal</u> constant will be converted to an 18-bit, two's complement data word. If the <u>literal</u> contains a decimal point and the radix is decimal, then the <u>literal</u> is

multiplied by the scale factor for numbers. Otherwise the <u>literal</u> is taken as it appears. In both cases only the integral part of the result is used and it must be less than 2¹⁷ in magnitude.

Examples:

PREDEFINE COUNT AS THE VALUE 10
PREDEFINE APERATURE AS THE VALUE -27.3127
PREDEFINE MASK AS THE VALUE OCTAL 770077
PREDEFINE PI AS THE VALUE SCALED 32768
3.1416

PRESET number VALUES OF noun TO THE CONSTANTS literals

This assembler directive may be used to initialize successive data locations to a set of fixed constants. If noun has been previously assigned a data address via

a PREDEFINE, PRESET, ALLOCATE, or ASSIGN directive, then the first literal will be loaded at the assigned address and the data location counter is unchanged. Otherwise noun is assigned the next available data location.

Storage is allocated for number locations by incrementing the data location counter by number. The sequence of literals will be loaded into successive memory locations starting at the address assigned to noun. In a program, noun will usually appear preceded by SUBSCRIPTED. During execution the subscript register would typically contain a value between 0 and number -1. The preset values may be modified during execution by machine instructions that store into memory.

Restrictions:

The memory addresses where the sequence of <u>literals</u> is initialized is not changed if noun is subsequently assigned another data location. If the same memory location is initialized more than once, then the last literal value will be in memory when the program is executed.

The <u>literal</u> constants will be converted to 18-bit, two's complement data words. Each <u>literal</u> that contains a decimal point and has a decimal radix is multiplied by the scale factor for numbers. Other <u>literals</u> are used as they appear. In both cases, only the integral part of the result is used and it must be less than 2¹⁷ in magnitude.

number must be equal to the number of constants. If noun was previsouly assigned a data location, then no check is made to determine if the number of constants is larger than the storage allocated to noun.

Examples:

PRESET 5 VALUES OF TABLE -1 TO THE CONSTANTS 10, -27.3127, OCTAL 770077, SCALED 32768, 99

THE RADIX FOR NUMBERS IS DECIMAL

This assembler directive is used in conjunction with the directive THE RADIX FOR NUMBERS IS OCTAL, and directs the assembler to use 10 as the base or radix in the conversion of numbers appearing in the program to their binary equivalents. This base is used from the occurrence of this directive until either the directive END OF THIS PROGRAM SEGMENT or THE RADIX FOR NUMBERS IS OCTAL appears. The

assembler will interpret all numbers appearing in the program as decimal numbers if no radix directive is used.

THE RADIX FOR NUMBERS IS OCTAL

This assembler directive is provided for those situations in which a large number of octal constants are used. It directs the assembler to use eight as the base or radix in the conversion of numbers appearing in the program to their binary equivalents. This base is used from the occurrence of this directive until either the directive END OF THIS PROGRAM SEGMENT or THE RADIX FOR NUMBERS IS DECIMAL appears. The assembler will interpret all numbers appearing in the program as decimal numbers if no radix directive is used.

Restrictions: Numbers converted using octal radix may not contain a radix point and must contain only the digits 0 through 7.

THE SCALE FACTOR FOR NUMBER IS number

This assembler directive changes the scale factor that the assembler uses for converting numbers, which contain a decimal point, to binary. The whole and fractional part of a number containing a decimal point are multiplied by the current assembler scale factor, number. The assembler uses a scale factor of 1.0 if no scale factor directive occurs. The scale factor number is used until either the directive THE SCALE FACTOR FOR NUMBERS IS or END OF THIS PROGRAM SEGMENT appears.

Restrictions: number is always converted to binary with a scale factor of 1.0.

Octal numbers that contain a radix point

will not be scaled.

Example: THE SCALE FACTOR FOR NUMBERS IS 1000.
LET .307 (METERS) YIELD MILLIMETERS PER FOOT.

THE SCALE FOR NUMBERS IS number

This assembler directive accomplishes the same function as the previous directive. The difference is that the scale factor for converting numbers is computed as 2 exp (number - 17); i.e., numbers will be scaled for the scale register setting specified by number.

verb OCTAL number

This assembler directive modifies the base or radix to eight for converting <u>number</u> to binary. This directive supersedes the directive THE RADIX FOR NUMBERS IS DECIMAL for conversion of this one <u>number</u>. The <u>verb</u> may be most machine verbs and most assembler directives. The form OCTAL <u>number</u> may be used anywhere <u>number</u> could be used in the assembly language.

Restrictions: number may not contain a radix point and

must contain only the digits 0 through 7.

Example: LET OCTAL 37777 PLUS OCTAL -101

verb DECIMAL number

This assembler directive modifies the base or radix to 10 for converting <u>number</u> to binary. This directive supersedes the directive THE RADIX FOR NUMBERS IS OCTAL for conversion of this one <u>number</u>. The verb may be most machine verbs and most assembler directives. The form DECIMAL <u>number</u> may be used anywhere <u>number</u> could be used in the assembly language.

Restrictions: If the directive THE RADIX FOR NUMBERS IS

OCTAL has not been used, then the radix will

automatically be decimal.

Example: LET DECIMAL 99 TIMES DECIMAL 3.14.

verb SCALED number literal

This assembler directive causes <u>number</u> to be used as the scale factor for converting <u>literal</u> to binary. The whole and fractional part of <u>literal</u> are multiplied by <u>number</u>. The integer part of the product is the resulting binary number. This directive supersedes the directive THE SCALE FACTOR FOR NUMBERS IS for conversion of this one <u>literal</u>.

Restrictions: number is always converted with a scale

factor of 1.0.

<u>literal</u> must contain a decimal point and the current radix must be decimal.

the current radix must be decimal.

Examples: LET SCALED 1000 .297

PLUS DECIMAL SCALED 100 47.25

Label Definition and Subscripting -

DEFINING noun

This assembler directive is used to define a position in a sequence of machine instructions. The noun should appear somewhere in this program segment as the object of a GO TO, THEN GO TO, RETURN FROM, TRANSFORMED BY, PERFORM, or EXECUTE machine verb. A data location will be assigned for noun when the END OF THIS PROGRAM SEGMENT directive is encountered. This data location will be preset with a value equal to the instruction address where the DEFINING directive occurred.

Restrictions: The only other assembler directive that noun may occur with is START THE FOLLOWING INSTRUCTIONS AT LOCATION noun.

When using noun as the object of LET-, PLUS-, and YIELD-type machine verbs, the data location referred to by noun is expected to contain an instruction address. If noun is used as the object of TRANSFORMED BY or PERFORM machine verbs, then two successive locations are preset to the instruction address where the DEFINING directive occurred.

DEFINING FOR EXTERNAL USE noun

This assembler directive is used to define a position in a sequence of machine instructions that may be referred to by other separately assembled programs or subroutines. The noun may appear as the object of GO TO, THEN GO TO, RETURN FROM, TRANSFORMED BY, PERFORM, or EXECUTE machine verbs in this program and other programs. A data location will be assigned for noun when the END OF THIS PROGRAM SEGMENT directive is encountered. Two data locations are reserved and the second is preset with a value equal to the instruction address where the DEFINING FOR THERNAL USE directive occurred.

Restrictions: The only other assembler directive that noun may occur with is START THE FOLLOWING INSTRUCTIONS AT LOCATION noun.

noun may be used as the object of LET-,
PLUS-, and YIELD-type machine verbs only in the program where it is defined. The data location referred to by noun is expected to contain an instruction address.

verb SUBSCRIPTED noun

This directive is used between a machine verb and its object $\underline{\text{noun}}$. Bit position 13 of the machine instruction is set to 1. When the machine instruction is exe uted, the data address referred to in memory is that of $\underline{\text{noun}}$ plus the content of the subscript register.

Restrictions: verb must be a machine verb that requires a noun.

noun will normally appear in an ALLOCATE, PRESET, or ASSIGN assembler directive.

Example: LET SUBSCRIPTED VECTOR TIMES SUBSCRIPTED VECTOR YIELD PARTIAL DOT PRODUCT

Connectives -

Connectives do not generate machine instructions or assembler directives but function only as a means of making the assembly language text more readable, while preserving the verb-noun syntactic pattern. Upon recognition of a connective, the assembler continues with the processing of the next syntactic element. The following is a list of the connectives:

- LET IT
- IF IT
- BE
- OTHERWISE
- AND ALSO

Connectives may be used anywhere a verb may be used. They may not be used as nouns.

Example:

LET A PLUS B YIELD C. LET IT PLUS D YIELD E. IF IT IS LESS THAN 5 THEN GO TO ALPHA.

OTHERWISE GO TO BETA.

SET EXTENSION WITH X2 AND ALSO LET X1 BE.

RETURN FROM THIS ROUTINE.

Relocatable Loader

The assembler produces relocatable code and data except when it encounters a directive, such as START THE FOLLOWING DATA AT LOCATION

number, which uniquely specifies where this code or data will be located. This means that code or data addresses are relative to the beginning code or data address assigned by the loader such that programs and data sets will be automatically stacked in core without overlap and without unused storage locations. The beginning bias for data and code is presently 210 and 4000 octal respectively, where locations 0 to 210 are used for input/ output and interrupt storage, and 4000 octal is the mid-point of a 4K memory module. As will be seen in the control card description, these starting biases may be altered. Figure 1 and Figure 2 illustrate the assembly of a program to calculate the combinations of n things taken k at a time and how the assembled program and data would be loaded into memory for execution. This example shows two assemblies - a main calling program and a subroutine which returns n! Figure 1 lists the two programs to be assembled, COMBINATIONS and FACTORIAL. Figure 2 indicates how these two programs would be loaded into OBP memory where the data for COMBINATIONS occupies locations 210 through 221 and the data for FACTORIAL is between location 222 and 234, all numbers being in octal. The code for COMBINATIONS and FACTORIAL are loaded into locations 4000 4023 and 4024 - 4046 respectively. Another feature of the loader is that a binary tape can be built up which contains many assembled program segments and certain of these assemblies can be selectively loaded.

Simulator

The functional simulator reads the absolute memory image tape created by the loader into core and simulates the execution of that program. When a HALT is encountered, the simulator prints out statistics concerning simulated running time and frequency of instruction usage. By means of various control cards, the simulator may be made to give selective tracing and/or dumping in either an octal or decimal mode. Control cards are also available for specifying periodic interrupts, simulation of input from the I/O unit, and such miscellaneous capabilities as halts treated as no-ops and restarting after a halt has been executed.

Interrupt Simulation - At the completion of each simulated instruction, the interrupt processor senses if any of the 15 external interrupts appeared during the simulation of the previous instruction. When an interrupt appears, the comment: INTERRUPT n HAS APPEARED AT time is written on the printer. If the interrupt cannot be honored immediately, it is saved and the word SAVED is printed on the same line as the above comment. If an interrupt is currently being saved and another of the same number appears, it is lost and the word LOST is printed. When an interrupt is honored, the comment: INTERRUPT n HONORED AT time is printed.

Input/Output Simulation - When an I/O instruction is simulated, the content of storage at the effective address is sent to the simulated I/O unit as a command. The simulated I/O unit interprets bits 17 and 18 of this function word to determine the function code and interprets bits 1 to 16 to identify the I/O device.

ASSEMBLE COMBINATIONS PRINT

ASSEMBLER FOR THE ON-BOARD PROCESSOR STANDARD VERBS AVAILABLE

THE RADIX FOR NUMBERS IS OCTAL
PREDEFINE NUMBER OF COMBINATIONS AS THE VALUE 400001
PREDEFINE NUMBER OF ITEMS PER GROUP AS THE VALUE 600001
PREDEFINE NUMBER OF ITEMS AS THE VALUE 500001
THE RADIX FOR NUMBER IS DECIMAL.
SET SCALE WITH 17.

LET INPUT FROM NUMBER OF ITEMS YIELD N. LET N TRANSFORMED BY FACTORIAL YIELD N FACTORIAL. LET INPUT FROM NUMBER OF ITEMS PER GROUP YIELD M. LET M TRANSFORMED BY FACTORIAL YIELD M FACTORIAL. LET N MINUS M TRANSFORMED BY FACTORIAL TIMES M FACTORIAL YIELD DENOMINATOR. LET N FACTORIAL OVER DENOMINATOR. BE OUTPUT TO NUMBER OF COMBINATIONS.

HALT END OF THIS PROGRAM SEGMENT

S ASSEMBLE FACTORIAL PRINT

ASSEMBLER FOR THE ON-BOARD PROCESSOR STANDARD VERBS AVAILABLE

(RETURN FROM) FACTORIAL. IF IT IS EQUAL TO Ø THEN GO TO ANSWER EQUALS ONE: DEFINING JAIL. LET N MINUS 1 YIELD N. IF IT IS LESS THAN 2 THEN GO TO DEFINING FOR EXTERNAL USE FACTORIAL. IF IT IS LESS THAN Ø THEN GO TO GO TO JAIL. DEFINING ANSWER EQUALS ONE, LET 1 BE. RETURN FROM FACTORIAL. DEFINING ANSWER. LET RESULT BE. RETURN FROM FACTORIAL. ANSWER; OTHERWISE, LET RESULT TIMES N YIELD RESULT. OTHERWISE LET IT YIELD N AND ALSO YIELD RESULT. END OF THIS PROGRAM SEGMENT.

Computer Listing of Main Program (COMBINATIONS) and Subroutine (FACTORIAL). Figure 1.

OCTAL LOCATION LOADED		OCTAL LOCATION ASSEMBLED
00000	INTERRUPT LOCATIONS	
0 0 0 2 1 0	DATA	0 0 0 0 0 0
0 0 0 2 2 1	(COMBINATIONS)	0 0 0 0 1 1
0 0 0 2 2 2	DATA	0 0 0 0 0 0
0 0 0 2 3 4	(FACTORIAL)	0 0 0 0 1 3
0 0 0 2 3 5	DAMA	0 0 0 0 0
	<u>DATA</u> (OTHER PROGRAMS)	
004000	CODE	0 0 0 0 0
0 0 4 0 2 3	(COMBINATIONS)	0 0 0 0 2 3
004024	CODE	0 0 0 0 0 0
004046	CODE (FACTORIAL)	0 0 0 0 2 3
0 0 4 0 4 7	CODE	0 0 0 0 0 0
	(OTHER PROGRAMS)	
	•	

Figure 2. Core Image Diagram of Automatic Code and Data Relocation

When the I/O instruction is simulated, the OBP simulator writes the following comment on the printer:

**** contents of effective address IS SENT TO I/O UNIT.

When the I/O simulator interprets the function word and successfully carries out the operation, it continues this comment by writing one of the following phrases on the same line.

Function Code	<u>Phrase</u>
0	No phrase
1	No phrase
2	THE DATA WORD contents of the accumulator IS OUTPUT TO I/O DEVICE $\frac{1}{1}$ bits 1 to 16 of function word.
3	THE DATA WORD next available data word for the designated I/O device IS INPUT FROM I/O DEVICE Bits 1 to 16 of function word.

NOTE

The current simulation time is also printed with the above comments. It should be noted that the I/O comment is printed regardless of whether or not the simulation is being traced.

Function codes 0, 1, or 2 may specify an I/O device identification ranging from 0 to 2^{16} -1. However, the I/O device identification is limited to 0, 1, 2, or 3 for function code 3 for simulation purposes. If any other device identification is specified, the comment

ILLEGAL I/O DEVICE SPECIFIED

will be written on the printer and the I/O operation will be considered complete with no further action.

If function code 3 specifies a legal I/O device, say \underline{n} , which has no more data, the comment

OUT OF DATA FOR I/O DEVICE n

will be written on the printer and the I/O operation will be considered complete with no further action. When the input/output simulation is completed, the next sequential instruction is simulated.

Description of Dumps and Traces - A dump is a printout of the contents of memory and generally comprises two parts: data and code. By means of the several simulator control cards, the user can control the dump to suit his needs. A dump may be decimal or octal; the entire memory may be dumped or just a specific segment. A dump may be printed upon simulation of a HALT instruction or at any specific point in the program execution. Likewise a trace, the printout of register contents during execution, has almost as many optional forms as the dump and is also user controlled to suit specific needs. Examples of dumps and traces with their various columns explained are discussed in the following paragraphs.

Decimal Dump - A decimal dump is a printout of memory within specified limits at a particular time (refer to Figure 3). The first column on the left is the decimal address. The entire dump is broken into several sections, the first of which is always a printout of the content of the interrupt locations. The remainder of the dump comprises a scaled decimal printout of the content of memory at the data locations occupied by the various programs and subroutines located within the specific limits of the dump, and a verb-noun listing of the code locations. The name of the program or subroutine is given as a heading and is followed by the initial and final addresses of the segment of memory which it occupies. Each program or subroutine is printed out in two parts: data (a decimal listing of the data words and their addresses) and code (a verb-noun listing of the code words and their addresses).

Octal Dump - An octal dump is a printout of memory within specified limits at a particular time. There are two columns of initial octal addresses and 16 columns of octal code or data words (refer to Figure 4). Starting from the left, column 1 and column 10 list the initial addresses of the following eight memory locations. Each set of eight columns (columns 2 through 9 and columns 11 through 18) presents a printout of the content of memory at that particular location. The entire dump is broken into several parts, the first of which is always a printout of the content of the interrupt locations. The remainder of the dump comprises a printout of the contents of memory at the locations occupied by the various programs and subroutines located within the limits of the dump. The name of the program or subroutine is given as a heading and is followed by the initial and final addresses of the segment of memory which it occupies. Each program or subroutine is dumped in two parts: data (an octal listing of the data words and their addresses) and code (an octal listing of the code words and their addresses).

INTERRUPT LOCATIONS				
5 .000000000 .0000000000 .0000000000 .135	10,0000000000	0000000000	0000000000	
COMBINATIONS (DATA) 136- 145				
13665535_000000000065535_0000000000 141 3_0000000000 6_0000000000	16,9999990000	2,0000000000	000000000000000000000000000000000000000	
COMBINATIONS (CODE) 2048- 2067				
2048 SET SCALE WITH 17 2051 LET (IF) N 2054 INPUT/OUTPUT FRO NUMBER OF IT YIELD 2057 TRANSFORMED BY FACTORIAL YIELD 2060 MINUS M 2063 YIELD DENOMINATOR 2063 YIELD DENOMINATOR 2066 INPUT/OUTPUT FRO NUMBER OF CO HALT	BY FACTORIAL BY M MEACTORIAL MFACTORIAL BY FACTORIAL NFACTORIAL	YIELD YIELD LET (IF) LET (IF) TIMES OVER	N NFACTORIAL M N MFACTORIAL DENOMINATOR	
FACTORIAL (DATA) 146- 153				
146 2062,000000000 2068,00000000 151 1,000000000 2080,00000000	0000000000	2,0000000000	2069,999900000	
FACTORIAL (CODE) 2068- 2081				
2068 YIELD N YIELD 2071 MINUS 1 YIELD 2074 IS LESS THAN 1 THEN GO TO 2077 TIMES N YIELD 2080 LET (IF) RESULT GO TO (RETURN	RESULT N ANSWER RESULT RN FACTORIAL	LET (IF) LET (IF) LET (IF) GO TO (RETURN	N N RESULT JAIL	
REMAINING CORE IN DATA REGION				
2044 .0000000000 .0000000000	0000000000	0000000000		
REMAINING CORE IN CODE RECION	•			

Figure 3. Computer Printout of Decimal Dump

Figure 4. Computer Printout of Octal Dump

Decimal Trace (Figure 5)

Column Explanation

LABEL This heading refers to the words in the first

column that stand alone on a line. These words are the labels used in GO TO, THEN GO TO, TRANSFORMED BY, RETURN FROM, and PERFORM

instructions.

INSTRUCTION This column gives a fully spelled-out listing of

the instruction being simulated.

OPERAND This lists the first 12 characters of the operand

name used with the instruction if the name is

available.

OPERAND VALUE This column gives the value of the operand

stored in memory converted to a decimal number using the current value of the scale register to

position the decimal point.

ACCUMULATED RESULT This column presents the accumulated result after

the simulation of each instruction converted to a decimal number using the current value of the scale register to position the decimal point.

TIME This column lists the cumulative total time in

microseconds for the execution of instructions.

Octal Trace (Figure 6)

<u>Column</u> <u>Explanation</u>

IC This column lists the value contained in the

Instruction Counter for each simulated instruction. The words that appear in this column but stand alone on a line are the labels used in GO TO, THEN GO TO, TRANSFORMED BY, RETURN FROM, and

PERFORM instructions.

INSTR This column gives an 8-letter abbreviation of the

instruction just simulated.

OPERAND This lists the first twelve letters of the oper-

and name used with the instruction if the name

is available.

				591,25		
TIME	402,50 410,00 415,00	421.25 427.50 435.00 441.25 447.50 447.50 522.50 532.00 535.00	541.25 547.50 555.00 561.25 567.50 572.50 578.75	591,25	602.50 610.00 616.25 626.25	633,75 641,25 647,50 653,75 661,25
ACCUMULATED RESULT	119,9999990000 119,9999990000	2,000000000 1,0000000000 1,000000000 1,00000000	1.0000000000 .0000000000 .0000000000 .000000	119,999990000 0 FROM DEVICE 1	3.0000000000 3.0000000000 3.00000000000	3.000000000 3.000000000 3.000000000 2.000000000 2.000000000
ACCUM	119,99 119,99	2,00 1,00 1,00 1,00 1,00 1,00 1,00 1,00	0.00 .00 .00 .00 .00 .00 .00	119,99999000 3,000000000 FROM DEVICE	8 6 6	2.00
	Q Q		00000		000	00000
OPERAND VALUE	2,0000000000 119,999990000	2.630000000 1.0000000000 1.000000000 1.00000000	1,0000000000 1,0000000000 ,0000000000 1,00000000	119,999990000	_65535_0000000000 3_0000000000 3_0000000000	3.000000000 3.000000000 1.000000000 2.000000000 2.000000000
				00003)	Ÿ	
				INPUT DATA (000003)		
OPERAND	N RESULT JAIL	N I N I ANSWER RESULT N RESULT JAIL	N N N 1 ANSWER RESULT FACTORIAL	FACTORIAL	NUMBER OF II M M FACTORIAL	N RESULT N 1 N N N
	()	(W	⊋	THE I/O UN		
RUCLION	TIMES VIELD GO TO (RETURN FROM)	LET (IF) MINUS YTELD LET (IF) 4S LESS THAN THEN GO TO LET (IF) TIMES YTELD GO TO (RETURN FROM)	LET (IF) MINUS KIELD LET (IF) LE LESS THAN HEN GO TO ER LET (IF) LET (IF)	ACTORIAL YIELD **** 600001 IS SENT TO THE I/O UNIT.	INPUT/OUTPUT FROM YIELD LET (IF) TRANSFORMED BY ORTAL	
LABEL INSTRUCTION	TIMES VIELD GO TO IATE	LET (IF) MINUS YIELD LET (IF) THEN GO TO LET (IF) TIMES YIELD GO TO (RE	LET (IF) MINUS YIELD LET (IF) IS LESS TH THEN GO TO ANSWER LET (IF) GO TO (RE	YIELD *** 6000	INPUT/OU YIELD LET (IF) TRANSFOR	YIELD YIELD LET (IF MINUS YIELD LET (IF

Figure 5. Computer Printout of Decimal Trace

H					696,25	
TIME	311.25 317.50 325.00 331.25 336.25 342.50 406.25 413.75	425.00 431.25 438.75 445.00 450.00 456.25 520.00 527.50	538.75 545.00 552.50 558.75 563.75 570.00 633.75 641.25	652.50 666.25 672.50 677.50	688.75 696.25	707.50 715.00 721.25 731.25
			in the second of		.	
TS	000000 000000 000000 000000 000000		000000 000000 000000 000000 000000 00000	0000000	000000 000000	000000
EAR	000226 000231 000226 000232 000233 000227 000226	000226 000231 000226 000232 000227 000227 000227	000226 000231 000226 000232 000227 000227 000227	000226 000231 000226 000232 000233	000222 000215 00 FROM I	000210 000216 000216 000222
x ss	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0 000000	8	0 000000
Δı	888888888	88888888	888888888	88888	38 8	8888
MEM	200226 240231 600226 260232 420233 440226 600227	200226 240231 600226 260232 420233 200227 440226 600227	200226 240231 600226 260232 420233 200227 440226 600227	200226 240231 600226 260232 420233	620222 620222 600215	160210 600216 200216 060222
S	ដដដដដដដដ	*******	***********	44444 5	12 2	ដដដដ
ACDO	0100 0100 0100 0100 0100 0100 0100	0100 0100 0100 0100 0100 0100 0100	0100 0100 0100 0100 0100 0100 0100	0100 0100 0110 0110	0100	0100 0100 0100 0100
EA	000000 000000 000000 000000 000000 00000	000000 000000 000000 000000 000000 00000	000000 000000 000000 000000 000000	000000		000000 000000
AC	000005 000004 000004 000004 000322 001510 001510	000004 000003 000003 000003 0005730 004730	000003 000002 000002 000002 004730 011660 011660	000001 000001 000001 000001 000001	011660 011660 1NPUT	000003
MOR	000005 000001 000002 004043 000322 000004 001510 004032	000004 000001 000003 004043 001510 00003 004730	000003 000001 000002 004043 004730 00602 011660	000002 000001 000001 004043	004005 004005 011660 UNIT.	600001 000003 000003 0C4012
OPERAND	N 1 1 N 2 ANSWER RESULT N RESULT JAIL	N 1 N 2 ANSWER RESULT N RESULT JAIL	N 1 N 2 ANSWER RESULT N RESULT	N 1 N 2 ANSWER	IAL ORIAL E I/O	NUMBER OF IT M M FACTORIAL
INSTR	LET (IF) MINUS YIELD IS LESS THEN GO LET (IF) THENES YIELD GO TO	HET (IF) MINUS YIELD IS LESS THEN GO IET (IF) TIMES YIELD GO TO	LET (IF) MINUS YIELD IS LESS THEN GO LET (IF) TIMES YIELD GO TO	LET (TF) MINUS YTELD IS LESS THEN GO		INPUT/OU YIELD LET (IF) TRANSFOR
ដ	JAIL 004032 004033 004034 004036 004036 004037 004040 004041	JAII. 004032 004033 004034 004035 004036 004040 004041 004042	JAIL 004032 004033 004034 004035 004035 004040 004040 004041	JAIL 004032 004033 004034 004035 004035	004004 GO TO PACTORIAL 004005 YIELD	004006 004007 004010 004011

Figure 6. Computer Printout of Octal Trace

Octal Trace (Figure 6) (Continued)

Column	Explanation
MOR	This is a printout of the value contained in the memory operand register after each simulated instruction.
. AC	This column shows the value contained in the accumulator after each simulated instruction.
EA	This column shows the value contained in the extended accumulator after each simulated instruction.
ACDO	This lists the value contained in each of the following one-bit registers: AND/OR, carry, decision, and overflow after each simulated instruction.
S	This column presents the value of the scale register after each simulated instruction.
MEM	This is a printout of the contents of memory at the address indicated by the instruction counter prior to simulation of each instruction.
P	This lists the value of the page register after each simulated instruction.
SS	This column gives the value contained in the subscript register after each simulated instruction.
X	For each instruction, the value listed here is a one if bit 13 of the instruction contains a one, thus designating use of the subscript register to determine the effective address.
EAR	This gives an instruction-by-instruction listing of the contents of the effective address register. The content of this register specifies the memory address of the operand.
SL	This column lists the contents of the storage limit register after each simulated instruction.

Octal Trace (Figure 6) (Continued)

Column

Explanation

TIME

This column presents the cumulative total time in microseconds for the execution of instructions.

Ι

This is a listing of the interrupt number being processed, if any interrupts have occurred during the simulation.

Control Cards

All control cards must have a ; (11/8/6) punched in column one. The function follows with blanks being disregarded. Thereafter, one or more blanks are used as delimiters. No control function can be continued onto a second card. Anywhere number appears, a decimal radix will be assumed unless OCTAL is specified; i.e., 11 is 11_{10} , but OCTAL 11 is 9_{10} .

; DATE characters

This card causes the first 12 nonblank (blanks are delimiters) characters to be printed as a part of the heading printed by the major functions (Assembler, Loader, etc.). For example, 7/4/8, 1400 could be used for date and time on the listing for the current run.

ASSEMBLE name PRINT NOLIST EDIT AUGMENT

This card causes the execution program to call in the assembler to assemble a program designated by name and to inform it of the options desired by the user. The output of the assembler is accumulated on the assembly tape. Only the first twelve characters of name are retained, any remaining characters are ignored. There must be no blanks interspersed in a program name. The remaining control card fields are optional, and if used their format is free form with blanks used as separators.

Options:

PRINT - If this word is present on the control card, the assembler will print out a statement by statement listing of the source language input.

NOLIST - This option directs the assembler to suppress the card image printout. If this option is not present, then a card image listing of the program being assembled will be given.

EDIT - This option allows the user installation to use its own mnemonics in place of the distributed verb phrases. The editing procedure assumes a deck setup as shown in Figure 7. Each card of the editing deck must have the format indicated. In particular, each new verb phrase must be accompanied by the exact number code of the standard verb which it will replace. This option will cause the new verb table to be punched out in the form of data statements representing the internal tree structure of the verb table. The installation must then place this punched output in the subroutine VERB according to the comments given in that subroutine.

AUGMENT - This option allows the user to temporarily include mnemonics of his own choosing for the program which he is assembling. The AUGMENT option assumes the same deck setup as the EDIT option and must precede each source deck. The new verb phrases are valid only for the current assembly.

; MEMORY SIZE IS number

This card designates the memory size to be loaded, simulated, or listed. The <u>variable</u> number must have a value of either 4096 or 8192. If this control card is missing, a memory size of 4096 is assumed.




Figure 7. Deck Setup for EDIT and AUGMENT

```
PROGRAM NAME 1, PROGRAM NAME 2, . . . , PROGRAM NAME n

; LOAD $

; LOAD program name

; LOAD program name DATA AT number AND CODE AT number
```

The ; LOAD program name card loads the entire assembly tape into core and then writes the On-Board Processor core image onto the absolute core image tape. The loader will assume a starting location of octal 210 for data.

When an 8K memory is being loaded, a starting location of octal 10000 is assumed for code, whereas octal 4000 is assumed when loading a 4K memory. The relative origins assumed by the loader may be altered by using the optional; LOAD program name DATA AT number AND CODE AT number card. If the user chooses to alter the assumed origins, care should be exercised to prevent data words from overlapping a block 4096 words. For example, if a program is loaded with data beginning at location 4000 and there are 100 words of data, then the first 96 words must be accessed with a page register setting of zero, and the remaining four words must be accessed with a page register setting of one.

The ; LOAD \$ indicates selective loading to the loader. The program names listed on the following cards will be loaded from the assembly tape. There must be a blank in column 1 of the program name cards but as many cards as needed may be used. However, the number of specified programs is limited to 25. The order in which the specified programs are loaded is the order in which they appear on the assembly tape. The relative origins assumed by the loader during selective loading may be altered by using the optional; LOAD \$ DATA AT number AND CODE AT number card.

: REWIND ABSOLUTE CORE IMAGE TAPE

; REWIND ASSEMBLY TAPE

Either of these cards causes the specified tape to be rewound.

PAUSE

This card will cause the OBP executive routine to pause. This option is included to allow the 920 user to switch tapes, save tapes, or hang tapes if necessary during his run

END OF FILE ON ASSEMBLY TAPE

This card causes an end-of-file record to be written on the assembly tape. This is to be used if and only if the file of relocatable programs on the tape is to be used at a later time.

SAVE PREVIOUS ASSEMBLIES

This card causes the executive routine to space down the assembly tape until an end-of-file record is read. The assembly tape is then backspaced over the EOF record, thus positioning it for further assemblies.

• DELETE name FROM PREVIOUS ASSEMBLIES

This card causes the executive routine to search the assembly tape and delete the assembly specified. All other assemblies are preserved. The end-of-file record is removed, and the assembly tape positioned for further assemblies. If a routine is to be reassembled with an assembly tape containing a previous assembly by the same name, the above card should be used to remove the old routine before the new routine is assembled.

LIST

; LIST THE NOUN TABLE ALPHABETICALLY NUMERICALLY

This card causes the executive to read in the absolute core image tape prepared by the loader. It then will list the complete noun table of all the loaded programs. The

order of the two options is irrelevant and either one or both may be omitted. If both are omitted, then numeric and alphabetic lists will be given. Both lists may also be obtained with the abbreviated control card; LIST.

Options:

ALPHABETICALLY - This option causes the alphabetically ordered noun table to be printed.

NUMERICALLY - This option yields a printed list of the nouns used ordered on the relocated addresses assigned to the nouns.

: LIST THE ABSOLUTE CORE IMAGE TAPE

This card causes a complete listing of the absolute core image. The core image, allocation table, and noun table is read from the absolute core image tape produced by the loader. The allocation table is then used to list data and code for each program segment. Data is listed in an octal format. Code is listed as the octal bit pattern for each instruction, with the decoded verb-noun phrases and labels as they were defined in the program. All indirect instructions are flagged with the indirect address.

: CHECK PRINT XX

This card causes the executive to turn on debugging flags within the OBP software package. This control option is provided as an aid in maintaining the OBP package and should be used only as directed by GSFC personnel.

Simulator Control Cards

The control cards for the simulator are grouped into the following six categories: starting, tracing, dumping, interrupting, inputting, and stopping (and/or restarting).

The format for the simulator control cards is the same as the format for the control cards discussed in Control Cards section, page 42.

Column one must contain a; (11/8/6 punches) and columns 2 through 80 contain the control information. One or more blanks are used as delimiters. No control function may continue onto a second card.

; SIMULATE name

This control card causes the simulator to be loaded into memory. The simulator sets the instruction counter to the load location of <u>name</u>. If <u>name</u> is omitted, then the instruction counter will be set to the normal, initial load location for instructions. The simulator is then ready to interpret any remaining simulator control cards. This card must be placed between the LOAD control card and the START control card.

; START AT number or label

This control card, or one of its optional forms, should appear as the last control card. It causes the simulator to commence simulating at the location specified by the SIMULATE function. The optional form, where number or label is specified, causes the simulation to commence at the location specified.

; TRACE

This card causes the simulator to print tracing information in the decimal mode for each relocatable instruction simulated.

: TRACE OCTALLY

This control card causes the simulator to print tracing information in the octal mode for each relocatable instruction simulated.

; TRACE FROM <u>label</u> or <u>number</u> TO <u>label</u> or <u>number</u>

This card causes the simulator to print tracing information for each instruction simulated between the limits specified in the decimal mode by label and/or number.

; TRACE OCTALLY FROM <u>label</u> or <u>number</u> TO <u>label</u> or <u>number</u>

This card causes the simulator to print octal tracing information for each instruction simulated between the limits specified by <u>label</u> and/or number.

; TRACE PROGRAM name

This control card causes the simulator to print decimal tracing information where the limits of $\underline{\text{name}}$ are taken from the allocation table.

; TRACE OCTALLY PROGRAM name

This card causes the simulator to print tracing information in the octal mode where the limits of <u>name</u> are taken from the allocation table.

; DUMP AT label or number

This control card causes a decimal dump of the entire memory when the specified location is accessed (either code or data).

; DUMP OCTALLY AT label or number

This card causes an octal dump of the entire memory when the specified location is accessed (either code or data).

; DUMP AT <u>label</u> or <u>number FROM label</u> or <u>number TO label</u> or <u>number WITH SCALE FACTOR number</u>

This card causes a decimal dump of the segment of memory located within the limits specified by the second the third <u>label</u> or <u>number</u> when the location specified by the first <u>label</u> or <u>number</u> is accessed. The user denotes the scale factor to be used in generating the dump.

; DUMP OCTALLY AT label or number FROM label or number TO label or number

This card causes an octal dump of the segment of memory located within the limits specified by the second and third <u>label</u> or <u>number</u> when the location specified by the first <u>label</u> or <u>number</u> is accessed.

; DUMP AT <u>label</u> or <u>number PROGRAM</u> name WITH SCALE FACTOR number

When the location specified by <u>label</u> or <u>number</u> is accessed, this function causes a decimal dump of the single program specified by <u>name</u> where the limits of <u>name</u> are taken from the allocation table. The user denotes the scale factor to be used in the dump.

; DUMP OCTALLY AT <u>label</u> or <u>number PROGRAM name</u>

This control card causes an octal dump of the program specified by <u>name</u>, where the limits of <u>name</u> are taken from the allocation table, when the location specified by <u>label</u> or <u>number</u> is accessed.

; DUMP AT HALT

This control card causes a decimal dump of the entire memory at the time of simulation of a HALT statement.

; DUMP OCTALLY AT HALT

This control card causes an octal dump of the entire memory at the time of simulation of a HALT statement.

; INTERRUPT number EVERY number MICROSECONDS or MILLISECONDS or SECONDS STARTING AT number MICROSECONDS or MILLISECONDS or SECONDS

This card causes the specified interrupt (legal interrupts are 1 through 15) to occur at the specified interval beginning at the specified start time. The user must specify the time-measure of the interval length and start time in microseconds, milliseconds or seconds.

; INTERRUPT number EVERY number MICROSECONDS or MILLISECONDS or SECONDS

This control card causes the specified interrupt (legal interrupts are 1 through 15) to occur at the specified interval beginning at time zero. The user must specify the time-measure of the interval length to microseconds, milliseconds, or seconds.

; MAXIMUM TIME IS <u>number</u> MICROSECONDS or MILLISECONDS or SECONDS

This card will cause the simulation to cease at the specified simulation time. If this card is omitted, then a value of 5 milliseconds is assumed.

; MAXIMUM INSTRUCTIONS IS number

This control card causes the simulation to cease after the specified number of instructions has been executed. If this function is omitted, a value of 500 instructions is assumed.

Inputting Data

data data data data data data;
; DATA FOR INPUT DEVICE number USING SCALE REGISTER SETTING OF number

This is the control card used for inputting data. Data may be input by one of four different input units numbered zero through three. A total of 200 data words may be specified. The user should denote the setting of the scale register for the input data words. Immediately following this card are the cards of input data for the specified input unit. As many cards as needed may be used and the format of these cards is free form with one or more blanks used as delimiters. Column one must be blank. The last data word must be followed by a \$.

During the simulation, when the specified unit is referenced in the input command, the data words, which are converted in accordance with the specified scale register setting, are input one word per call until the buffer is exhausted.

It should be noted that if it is desired to supply the exact octal bit pattern for data words instead of converting a decimal number, then a scale register setting of 17 should be used regardless of the actual scale of the number supplied. For example, 0.5 with a scale register setting of zero may appear at input time as octal 177777, instead of octal 200000, because of truncation errors in the conversion process. However, octal 200000 with a scale register setting of 17 will appear at input time as octal 200000; i.e., 0.5 if the scale register is set to zero.

Stopping and/or Restarting - The normal means of ending a simulation is by simulating a HALT. Any remaining control cards will then be honored.

; NO HALT

This control card causes all HALT instructions to be simulated as PASS instructions.

RESTART AT HALT

This control card causes one HALT instruction to be simulated as a PASS instruction. There must be a RESTART AT HALT card for each HALT that is to be simulated as a PASS instruction.

; STOP AT HALT

This control card allows the HALT statement to be simulated normally. Its main purpose is to allow proper page skipping between multiple jobs.

Diagnostics

A set of CPU diagnostics exists which is aimed at testing the execution of all machine instructions in order of increasing complexity. The diagnostics consist of seven program assemblies and must be segmented into two parts with a 4K word memory since the total set of diagnostics requires approximately 4,500 words of memory. The diagnostics can be loaded into OBP memory at the GSFC installation using the SDS 920 computer. Then, the results of the diagnostics can be monitored with a program in the SDS 920 version of the support software system. The diagnostics can be set in a mode whereby when a test fails, the accumulator is loaded with a code word which indicates which test failed. Thus, diagnostics can be run independently of the SDS 920 and if a display console is connected to the CPU, test results will be automatically displayed. Future effort will be directed toward the development of a set of system diagnostics in which the input/output unit, memory, and peripheral devices, if possible, are also tested.

Library

The following subroutines have been added to the GSFC 920 system tape.

ARCTAN

Entry Points: ARCTAN

Accuracy: 10⁻⁵

Storage: 36 data words + 73 code words

Execution Time: 800 usec

Function: The argument in radians, scaled by the scale register, is received in the accumulator. The arctangent of the argument is computed and returned in the accumulator with the original scale setting. Overflow will be set if the result is larger in magnitude than 2^S where s is the content of the scale register.

EXPONENTIAL

Entry Points: E-EXPONENTIAL, 10-EXPONENTIAL, and 2-EXPONENTIAL

Accuracy: 10⁻⁴

Storage: 43 data words + 84 code words

Execution Time: 800 usec

Function: The argument X, scaled by the scale register, is received in the accumulator and is transformed by either e^X , 10^X , or 2^X depending on the entry point. The result returned in the accumulator has the original scale setting. Overflow will be set if the magnitude of the result is greater than 2^S , where s is the contents of the scale register.

LOGARITHM

Entry Points: NATURAL LOGARITHM, COMMON LOGARITHM, and LOG BASE - 2

Accuracy: 10⁻⁴

Storage: 41 data words + 100 code words

Execution Time: 800 usec

Function: The argument X, scaled by the scale register, is received in the accumulator and is transformed by either log (base e), log (base 10), or log (base 2), depending on the entry point. The result returned in the accumulator has the original scale setting and overflow will be set for negative arguments or for arguments less than 1 which yield a result larger in magnitude than 2 where s is the content of the scale register.

SIN/COS

Entry Points: SIN, COS, SINF and COSF

Accuracy: 10⁻⁴

Storage: 35 data words + 59 code words

Execution Time: 500 usec

Function: For the entries SIN and COS the argument is assumed to have a scale of zero and is expressed in fractions of PI/2. The argument X as received in the accumulator is transformed by either SIN (X) or COS (X) and returned in the accumulator. The cosine of 0 will be returned as $1-2^{-18}$. For the entries SINF and COSF, the argument X, in radians, with a scale determined by the scale register, will be transformed by either SIN (X) or COS (X) and returned in the accumulator with the original scale setting.

SQUARE ROOT

Entry Points: SQUARE ROOT

Accuracy: 10⁻³

Storage: 44 data words + 83 code words

Execution Time: 800 usec

Function: The double length argument X, with a scale setting equal to the contents of the scale register, is received in the accumulator; extended accumulator and is transformed by $(X)^{1/2}$ and returned in the accumulator with the original scale setting. Negative arguments will be returned as octal 400000 and overflow will be set.

PROGRAMMING NOTES

The support software which has been developed for the OBP was aimed at allowing independent programming by OBP users at different locations. In keeping with this philosophy, all I/O processing, interrupt processing, data decommutation and formatting, job sequencing, and storage limit control will be programmed by one group so that program integration and checkout problems will be minimized. The items under this section, then, that relate to some of these functions are presented to alleviate curiosity.

It is the current intent to be able to provide data and code linkage between an EXECUTIVE routine and OBP worker programs so that the author of the worker programs can assume his input data will be properly formatted and appear at a known place and he can operate on these numbers, using available mathematical subroutines, and deposit his output numbers in a known segment of storage, leaving all housekeeping duties to the central housekeeping group.

Input/Output

The OBP has two modes of input/output: program-controlled and cycle steal. For program-controlled I/O, either the contents of the accumulator is output to a device or the data from a device is input to the accumulator. For cycle steal operation, there are two cycle steal channels in the input/output unit which control block transfers of data between input/output devices and memory. These data transfers are independent of program execution and the external device supplies the I/O request pulses. The cycle steal channels provide memory addressing and either the gating of data from an external device onto a memory input data bus or select pulses to an external device, since for cycle steal output operations the data is broadcast to all devices. The initialization of a cycle steal channel may be accomplished either under CPU control by executing the appropriate I/O instruction or under external command control by receiving the appropriate ground command sequence. The following information is sent to the I/O unit to initialize a cycle steal channel:

- Starting address (16 bits) denotes the initial address of the data block to be transferred.
- Device (2 bits) specifies which device is to be connected to memory. A device will have different numbers for input and output.
- Control channel (1 bit) specifies which of two control channels is to be initialized. Note that control channel redundancy exists since a device can use either channel.
- Block length (12 bits) indicates the number of words to be transferred.

Once a channel has been initialized, it will remain active until either the block transfer is complete, at which time a block length = zero interrupt is produced, or until the channel is re-initialized.

The one I/O instruction results in four different actions depending on bits 17 and 18 of the contents of the effective address of the instruction. When the I/O instruction is executed, the content of the effective

address instruction is examined by the I/O unit so that harmony will exist between the I/O and the CPU. The four I/O operations resulting from executing the I/O instruction are shown in Table 2. The I/O unit is designed such that any device connected to the OBP can transfer data in and out of the accumulator by executing the I/O instruction. For input, 1,1 in bits 18, 17 and device number in bits 13-16 of the cell at the effective address is required. For output, 1,0 in bits 18, 17 and device number in bits 13-16 of the cell at the effective address is required. A subset of all devices, depending on the application, may be connected to memory through cycle steal control. Again, to effect this connection by program execution, the I/O instruction must be set up such that the contents of memory at the effective address has 0,0 in bits 18, 17; block length in bits 1-12, device number in bits 13-15 and cycle steal channel selection is made in bit 16. For initializing a cycle steal channel the accumulator must be loaded prior to executing the I/O instruction with the block starting address right justified. The fourth I/O action which occurs when bits 18, 17 of the content of the effective address are 0,1 will depend on the application since the remaining 16 bits of that memory word are available for any use by the I/O unit.

Factors to be considered in the choice of program controlled versus cycle steal I/O are:

- Hardware additional gating is required to add the capability of connecting devices to memory through a cycle steal channel.
- Timing the fastest program controlled I/O rate is limited by an I/O sequence consisting of:

DEFINING I/O ROUTINE

LET INPUT FROM DEVICE

YIELD SUBSCRIPTED BLOCK

STEP SUBSCRIPT BY 1 IF


SUBSCRIPT IS NOT GREATER

THAN BLOCK LENGTH THEN GO TO I/O ROUTINE

This routine for input and a similar one for output requires 37.75 usec to execute plus the time required to process interrupts needed to synchronize the data with program execution. Cycle steal I/O rates as high as 400 (10³) words/second are possible. Generally, program control of I/O is restricted to 1) devices for which the data transfers are program dependent or 2) very low frequency devices if interrupt of the program is necessary for synchronization.

TABLE 2

(M) INPUT/OUTPUT FORMAT



Interrupts

There is a 15 bit register in the I/O unit which stores interrupt requests. As each request is serviced, the corresponding bit in the register will be reset. There is another 15 bit register in the I/O, called the interrupt priority register, where each stage indicates whether or not an interrupt request at that level is to be locked out. An interrupt is sent to the CPU when the request bit is set and the corresponding bit of the interrupt priority register is zero. Should two allowable interrupts simultaneously request interrupts, there is a hard-wired 15 level priority circuit in the I/O unit (interrupt 1 is of highest priority) to determine which interrupt request is to be honored first. The interrupt priority register is set either when an interrupt is sent from the I/O unit to the CPU, or when the CPU executes an EXIT instruction, or when the CPU executes a RESUME instruction, the instruction normally executed at the termination of an interrupt routine. The interrupt priority is set by the contents of a memory word so that the determination of which interrupts are to be allowed can be dynamically changed. The one exception is that interrupt 1 has top priority and cannot be locked out. This interrupt will be used to initiate program execution. When an interrupt is received by the CPU, the instruction being executed will be completed and then an automatic sequence is entered in which the address of the next instruction to be executed, the contents of the storage limit register, the miscellaneous registers (page, scale, D, O/A, OV, and C), and the current status of the interrupt priority register are stored in a bank of four memory locations, NO to N3. the same registers will be loaded from the four memory locations N4 to N7. It is the programmer's responsibility to initialize locations N4 to N7, where N is the interrupt number, with the desired interrupt priority, miscellaneous register settings, storage limit setting and starting address of interrupt routine N. At the conclusion of interrupt routine N there must be a RESUME FROM N instruction which will result in returning control to the interrupted program and restoring the interrupt priority, storage limit, and miscellaneous registers. Of course, any addressable register which may be altered during the interrupt routine should be tucked away and uncovered upon entering and leaving the interrupt program.

Scale Register

The 6 bit scale register can be loaded from memory with the SET SCALE WITH <u>noun</u> instruction and the instruction LET SCALE maps the scale register onto bits 1-6 of the accumulator with the remaining accumulator bits being set to zero. The scale register is used to control the length of automatic double-length left shifts following multiply operations and right shifts preceding divide operations. The value of the scale register denotes the number of places to the right of the sign bit at which the binary point is located.

Fractional numbers have a scale of 0, and integers have a scale of Another convenient way of visualizing the scale register is if the contents of the scale register is s and the unscaled accumulator contents is X' where $0 \le X' < 1$, then the scaled number in the accumulator $X=2^{S}X'$. If two numbers are multiplied, the result should have the same scale as the arguments. That is, if $X=2^{S}X'$ and $Y=2^{S}Y'$, $X\cdot Y=2^{2S}\cdot X'Y'$. What is needed is for the product to be of the form $2^{s}(Z)$, thus $Z=2^{s}X'Y'$ which is a fractional multiplication of X times Y shifted left s places, exactly what occurs in hardware with the scale register. Similarly, for division $X/Y = 2^{S}X'/2^{S}Y' = X'/Y'$ but, to maintain the same scale, the quotient should be of the form 2SZ where Z=2-SX'/Y' which indicates a shift right by X by s places prior to division, again what is accomplished in hardware with the implementation of the scale registers. It is noteworthy that if two numbers with different scales, sl and s2, are multiplied with a scale register setting of s1 then the product will be scaled by s2. That is, for $X = X'2^{s1}$ and $Y = Y'2^{s2}$, $X \cdot Y = 2^{s1+s2}$ (X'Y'), but what the hardware produces is 2^{s1}(X'Y') for a scale register setting of s1. Therefore, $X \cdot Y = 2^{s1+s2}(X'Y') = 2^{s2}(2^{s1}X'Y')$ which is the product scaled at s2.

The scale register is also used to store the shift length of the NORMALIZE instruction. The NORMALIZE instruction performs a double-length shift left for up to 34 places until bits 1 and 2 of the accumulator are different. If the accumulator and extended accumulator contain all zeros, zero will be set into the scale register following a NORMALIZE. Since the NORMALIZE alters the scale register and multiply/divide operations always use the scale register, care should be taken when mixing these operations.

Program Linkage

The DEFINING <u>label/noun</u> assembler directive makes label/noun available as a transfer point within an assembled program segment. Each transfer, GO TO, THEN GO TO, RESUME FROM, and TRANSFORMED BY is indirect and the DEFINING statement makes the pointer available for loading into the referenced memory location when a transfer instruction is encountered. For program linkage between separate assemblies, a DEFINING FOR EXTERNAL USE statement makes that definition external and, during load time, if another assembly had the same undefined symbol, linkage is then made. All subroutines, then, must have a DEFINING FOR EXTERNAL USE preceding each entry point for providing linkage information. Two cells are reserved for subroutine entry points with the first used to hold the address to which control will return and the second holds the pointer to the entry point. When a TRANSFORMED BY instruction is executed the current instruction address +1 is written into the first word of the two word address block corresponding to the defined entry point X and the instruction counter is set to X, the contents of the second word. return point in a subroutine, then, should be a RETURN FROM (GO TO) X which automatically returns control to the calling program. If a routine has more than one entry point with a common return point, a procedure which may be used is that each entry point should store the return address in a dummy return point so that one return statement RETURN FROM DUMMY RETURN may be used. As an example, suppose that a SINE routine had three entry points corresponding to the input argument in radians, degrees, or fractions of pi/2. If the polynomial expansion assumed an argument in fractions of pi/2, the following code in the subroutine to allow correct linkage could be used:


DEFINING FOR EXTERNAL USE SIN 1 LET IT TIMES 2 OVER 3.1416 YIELD ARGUMENT. LET SIN 1 YIELD SUBROUTINE. GO TO COMPUTE. DEFINING FOR EXTERNAL USE SIN 2. LET IT OVER 90 YIELD ARGUMENT. LET SIN 2 YIELD SUBROUTINE. GO TO COMPUTE. DEFINING FOR EXTERNAL USE SIN 3. LET IT YIELD ARGUMENT. LET SIN 3 YIELD SUBROUTINE. DEFINING COMPUTE.....

RETURN FROM SUBROUTINE.


DEFINING SUBROUTINE. END OF THIS PROGRAM SEGMENT.

When writing separate program segments, it is advisable to leave code and data relocatable and let the loader provide linkage and absolute memory assignments. However, if it is necessary to make a block of code or data absolute, the following sequence permits the return to relocatable mode at the completion of the absolute segment.

Relocatable to absolute to relocatable data storage assignment;



Relocatable to absolute to relocatable code storage assignment:



Absolute

START THE FOLLOWING INSTRUCTION AT LOCATION number

START THE FOLLOWING INSTRUCTION AT LOCATION DUMMY

Relocatable

Storage Limit Register

The OBP has an 18 bit storage limit register which is used to enable blocks of memory into which writing is permitted. Those instructions which require writing into memory, and therefore consult the storage limit register, are YIELD, TRANSFORMED BY, SAVE EXTENSION IN, and SAVE SUBSCRIPT IN. The register is broken into two 9 bit fields - A and B - where A = (B1-B9) and B = (B10-B18), BI = the Ith bit of the storage limit register numbered from the right. A and B represent upper and lower limits on the 9 high order bits of a 16 bit effective address between which writing will be permitted. Stated symbolically, if C = (B8-B16) of the effective operand address for one of the four instructions listed above and A and B are the two fields of the storage limit register, then if $B \le C \le A$ write permitted, otherwise, write will not be permitted. Note that if A = B then one 128 word block is enabled whereas if A = (1,1....1) and B = (0,0....0) then all of memory is enabled.

A Programming Example

The example which follows was run on the GSFC 920 system. This example is the combinations routine which computes the number of combinations of n things taken k at a time and calls the routine factorial, which takes the factorial of positive entegers. The first control card is a DATE card which results in the date being listed tor assembler/ simulator printouts. The next control card is the ASSEMBLE card for COMBINATIONS using the print option which causes a line-by-line listing of assembly language statements which follows the card image listing. synopsis of storage allocation data follows each assembly listing. The assembly language deck for COMBINATIONS followed the ASSEMBLE COMBINATIONS control card. The first two pages of the listing are associated with the program COMBINATIONS. The next set of cards is the ASSEMBLE control card for the program FACTORIAL followed by the source deck for that program. The assembler again produces the printout shown on the third and fourth pages of listing for FACTORIAL. If the ASSEMBLE control card did not have PRINT following the program name, the line-by-line listing of source statements would not appear. The next input card was the LOAD control card which produces the printout on the fifth page of the example and, of course, performs a loading of the two assembled programs. A LIST THE ABSOLUTE CORE IMAGE TAPE control card followed the LOAD. This listing

shows the initial values of the data cells and decodes the program segments with all transfers flagged to show the indirect pointer. A sequence of control cards to provide a simulation and octal trace with input data followed. The octal trace continued until the program was finished, and the last part of the example shows the frequency of instruction using statistics which the simulator provides upon normal termination of a simulation.

; DATE 12/7/57

S ASSEMBLE COMBINATIONS PRINT

ASSEMBLER FOR THE ON-BOARD PROCESSOR 12/7/57

THE RADIX FOR NUMBERS IS OCTAL
PREDEFINE NUMBER OF ITEMS PER GROUP AS THE VALUE OCTAL 600001
PREDEFINE NUMBER OF ITEMS AS THE VALUE 600001
PREDEFINE NUMBER OF COMBINATIONS AS THE VALUE 400001
THE RADIX FOR NUMBERS IS DECIMAL.

SET SCALE WITH 17.
LET INPUT FROM NUMBER OF ITEMS YIELD N.

LET N TRANSFORMED BY FACTORIAL YIELD N FACTORIAL.
LET INPUT FROM NUMBER OF ITEMS PER GROUP YIELD M.
LET M TRANSFORMED BY FACTORIAL YIELD M FACTORIAL.
LET N MINUS M TRANSFORMED BY FACTORIAL TIMES M FACTORIAL

YIELD DENOMINATOR. LET " FACTORIAL OVER DENOMINATOR BE OUTPUT TO NUMBER OF COMBINATIONS. HALT.

END OF THIS PROGRAM SEGMENT.

**** ASSEMBLY LANGUAGE STATEMENTS FOR COMBINATIONS ***

```
STORAGE ASSIGNMENT FOR NOUNS AND LITERALS (LOCATION, TYPE/L=INDIRECT, A=ABSOLUTE LOC., B=I AND A/, NAME)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           0004
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             17
DENOMINATOR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    THE FOLLOWING SYMBOLS WERE MENTIONED BUT NOT USED IN ANY MACHINE INSTRUCTION
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             NUMBER OF CO 0003
M FACTORIAL 0010
                                                                                                                                                                            YIELD N FACTORIAL
LET INPUT FROM NUMBER OF ITEMS PER GROUP
THE RADIX FOR NUMBERS IS OCTAL PREDETIME NUMBER OF ITEMS PER GROUP AS THE VALUE OCTAL 600001 PREDETIME NUMBER OF ITEMS
                                                                                                                                                                                                                                                                                                                                                                       OUTPUT TO NUMBER OF COMBINATIONS
                                                                                   AS THE VALUE 400001
THE RADIX FOR NUMBERS IS DECIMAL
SET SCALE WITH 17
LET INPUT FROM NUMBER OF ITEMS
                                                          AS THE VALUE 600001
PREDEFINE NUMBER OF COMBINATIONS
                                                                                                                                                                                                                                                                                                                                                                                                  END OF THIS PROGRAM SEGMENT
                                                                                                                                                                                                                                                                                         FRANSFORMED BY FACTORIAL
                                                                                                                                                                                                                                    RANSFORMED BY FACTORIAL
                                                                                                                                                                  RANSFORMED BY FACTORIAL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 NUMBER OF IT 0002
M 0007
                                                                                                                                                                                                                                                                                                         THES M FACTORIAL TELD DENOMINATOR
                                                                                                                                                                                                                                                   KIELD M FACTORIAL
                                                                                                                                                                                                                                                                                                                                              OVER DENOMINATOR
                                                                                                                                                                                                                                                                                                                                 LET N FACTORIAL
                                                                                                                                                                                                                                                                                                                                                                                                                               0 *DIAGNOSTIC* MESSAGE(S).
                                                                                                                                                                                                                                                                                                                                                                                                                                                          DATA ADDRESS ASSIGNED
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    400001
                                                                                                                                           KIELD N
                                                                                                                                                                                                              TELD M
                                                                                                                                                                                                                                                                               AINUS M
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  NUMBER OF IT COOL
N FACTORIAL 0006
                                                                                                                                                                                                                                                                                                                                                                                                                                                            EXTERNAL DEFINITIONS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         UNDEFINED SYMBOLS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      1000009
                                                                                                                                                                                                                                                                                                                                                                                                                                    END OF LISTING.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    FACTORIAL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       0000
```

3 ASSEMBLE FACTORIAL PRINT

ASSEMBLER FOR THE ON-BOARD PROCESSOR 12/7/57

DEFINING FOR EXTERNAL USE FACTORIAL.

IF IT IS LESS THAN 0 THEN GO TO (RETURN FROM) FACTORIAL.

IF IT IS EQUAL TO 0 THEN GO TO ANSWER EQUALS ONE;
OTHERWISE LET IT YIELD N AND ALSO YIELD RESULT.

DEFINING JAIL. LET N MINUS 1 YIELD N.

IF IT IS LESS THAN 2 THEN GO TO ANSWER; OTHERWISE,
LET RESULT TIMES N YIELD RESULT.

GO TO JAIL.
DEFINING ANSWER. LET RESULT BE. RETURN FROM FACTORIAL.
DEFINING ANSWER. EQUALS ONE, LET 1 BE. RETURN FROM FACTORIAL.
END OF THIS PROGRAM SEGMENT.

*** ASSEMBLY LANGUAGE STATEMENTS FOR FACTORIAL ***

LOAD

LOADER FOR ON-BOARD PROCESSOR SOFTWARE 12/7/57

NATIONS 9 20	ງ ຕ → ·	00	10
PREAMBLE VALUES FOR COMBINATIONS DATA LENGTH	CODE LENGIH PRESET LOCATIONS LITERALS	INDIRECT ADDRESSES EXTERNAL DEFINITIONS	JUDEFINED SYMBOLS NOUNS
PREAMBL) DATA	CODE PRESE LITER	EXI	UNDEF

PREAMBLE VALUES FOR FACTORIAL DATA LENGTH CODE LENGTH PRESET LOCATIONS LITERALS INDIRECT ADDRESSES EXTERNAL DEFINITIONS UNDEFINED SYMBOLS OUNDEFINED SYMBOLS OUNDEFINED SYMBOLS

EXTERNAL DEFINITIONS FACTORIAL

CORE LIMITS
DATA 000210-000234 / CODE 004000-004046
STARTING ADDRESS 004000

CORE ALLOCATION

COMBINATIONS
DATA 000210-000221
CODE 004000-004023
FACTORIAL
DATA 000222-000234
CODE 004024-004046
END OF ALLOCATION

69

; LIST THE ABSOLUTE CORE IMAGE TAPE

ABSOLUTE CORE IMAGE LIST 12/7/57

			004024	,				004024				004024						
17	NUMBER OF IT	z z	FACTORIAL	N FACTORIAL	NUMBER OF IT	Ж	¥	FACTORIAL	M FACTORIAL	×	×	FACTORIAL	M FACTORIAL	DENOMINATOR	N FACTORIAL	DENOMINATOR	NUMBER OF CO	
SET SCALE WITH	INPUT/OUTPUT FROM	LET (IF)	TRANSFORMED BY	YIELD	INPUT/OUTPUT FROM	YIELD	LET (IF)	TRANSFORMED BY	YIELD	LET (IF)	MINUS	TRANSFORMED BY	TIMES	YIELD	LET (IF)	OVER	INPUT/OUTPUT FROM	HALT
							-											
32 0213	16 0211	20 0214	06 0222	60 0215	16 0210	60 0216	20 0216	06 0222	60 0217	20 0214	24 0216	06 0222	44 0217	60 0220			_	0000 00
004000	00400I	004003	004004	004005	900400	004007	004010	004011	004012	004013	004014	004015	910700	004017	004050	004021	004022	004023
	٠.,																	

		004024		004045							004043				004032		004024		004024
	. 0	FACTORIAL	0	ANSWER EQUAL	N	RESULT	Z	 1	Z	2	ANSWER	RESULT		RESULT	JAIL	RESULT	FACTORIAL	 1	FACTORIAL
	IS LESS THAN	THEN GO TO	IS EQUAL TO	THEN GO TO	YIELD	YIELD	LET (IF)	MINUS	YIELD	IS LESS THAN	THEN GO TO	LET (IF)	TIMES	YIELD	GO TO (RETURN FROM)	LET (IF)	GO TO (RETURN FROM)	LET (IF)	GO TO (RETURN FROM)
	FACTORIAL						JAIL		•							ANSWER		ANSWER EQUAL	
	0224	0222	0224	0225	0226	0227	0226	0231	0226	0232	0233	0227	0226	0227	0230	0227	0222	0231	0222
	26	42	46	42	09	09	20	24	9	56	42	20	4 4	09	62	20	62	20	62
-	004024	004025	004026	004027	004030	004031	004032	004033	004034	004035	004036	004037	004040	004041	004042	004043	004044	004045	940400

004024-004046

FACTORIAL

ABSOLUTE 004047-007777

; DATA FOR INPUT DEVICE I USING SCALE REGISTER SETTING OF 17

7 3 8

; SIMULATE ; TRACE OCTALLY

; START

ON-BOARD PROCESSOR SIMULATOR 12/7/57

н		r,																		
, =																				
TIME	5.00		16.25 23.75 30.00 40.00	46.25	57.50 62.50	70.00	83.75	97,50	108.75	178,75	186,25	191.25	197,50	203.75	217.50	222,50	228,75	292,50	300,00	305,00
		H																		
			2000		0.0		O 'O										_	_		_
Si	000000	EVICE	000000	000000	000000	000000	000000	000000	000000	00000	000000	00000	00000	00000	00000	00000	00000	00000	00000	000000
EAR	000213	FROM D	000211 000214 000214 000222	000224	000224	000226	000226	000226	000233	000226	000227	000230	000226	000231	000232	000233	000227	000226	000227	000230
×	0	000	0000	00	00	0 0	00	00	0	0	0	-	0 (> c	ò	0	0	0	0	0
SS	000000	7.0000000000 FROM DEVICE	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
Д	8	•	8888	88	88	88	88	88	88	38	8	8	8	88	8	8	8	8	8	8
MEM	320213		160211 600214 200214 060222	260224	460224 420225	600226 600227	200226 240231	600226 260232	420233	440226	600227	620230	200226	240231	260232	420233	200227	440226	600227	620230
S	21		22 22 22 22 22 22 22 22 22 22 22 22 22	12 12	21 21	21 21	21,	21	77	7 7	21	21	21	21.	17	21	21	21	21	21
ACDO	0000	(2000	00000	0000	0000	000	0100 0100	0100	0100	0010	0100	0100	0100	0100	0100	0100	0100	0100	0100	0100
EA	000000	DATA (000007	000000	000000	000000	000000	000000	000000	000000	000000	000000	00000	000000	000000	000000	000000	000000	000000	000000	000000
AC	000000	INPUT 1	000007	000007	000007	000007	000007	900000	900000	000052	000052	000052	900000	000005	000002	000000	000052	000322	000322	000322
MOR	000021	III.	600001 000007 000007 004005	000000	000000	000007	000000	000006	004043	900000	000052	004032	900000	100000 000005	000002	004043	000052	000002	000322	004032
OPERAND	17	r to the 1/0 unit	NUMBER OF IT N N FACTORIAL	O FACTOR: AL	O ANSWER EQUAL	N RESULT	z -	2 Z	ANSWER	N	RESULT	JAIL	z		5 :	ANSWER	RESULT	Z	RESULT	JAIL
INSTR	004000 SET SCAL	*** 600001 IS SENT TO THE	INPUT/OU YIELD LET (IF) TRANSFOR	IS LESS THEN GO	IS EQUAL THEN GO	YIELD	LET (IF) MINUS	YIELD IS LESS	THEN GO	TIMES	YIELD	0. 0. 0.	LET (IF)	MINUS	IS LESS	THEN GO	LET (IF)	TIMES	YIELD	05 05
SI.	0004000)009 ***	004001 004002 004003	.		004030	004032	004034	004036	004070	004041	UU4U4Z JAII	004032	004033	004035	004036	004037	004040	004041	240400
				174								7								

H					696,25	
TIME	311.25 317.50 325.00 331.25 336.25 342.50 406.25 413.75	425.00 431.25 438.75 445.00 450.00 456.25 520.00 527.50	538.75 545.00 552.50 558.75 563.75 570.00 633.75 641.25	652.50 658.75 666.25 672.50 677.50	696.25	707.50 715.00 721.25 731.25
					H	
ST	000000 000000 000000 000000 000000	0000000 0000000 0000000 0000000	000000 000000 000000 000000 000000 00000	0000000	000000 NEVICE	000000
EAR	000226 000231 000226 000232 000233 000227 000226	000226 000231 000226 000232 000227 000227 000226	000226 000231 000225 000232 000227 000226 000226	000226 000231 000226 000232 000233	000000 0 000215 0000 000000 0 000215 0000 3.0000000000 FROM DEVICE	000210 000216 000216 000222
SS	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	0 0000000 0 0000000 0 0000000 0 0000000 0 000000	0 0000000 0 0000000 0 0000000 0 0000000 0 000000	0 000000	0 00000000	0 000000
ρ.	888888888888888888888888888888888888888	868888888888888888888888888888888888888	888888888888888888888888888888888888888	88888 88		8888
MEM	200226 240231 600226 260232 420233 200227 440226 600227	200226 240231 600226 260232 420233 200227 440226 600227	200226 240231 260226 260232 420233 200227 440226 600227 620230	200226 240231 600226 260232 420233 200227	600215	160210 600216 200216 060222
S	222222222	22222222	22222222	ដដដដដ ដ	77	2222
ACDO	0100 0100 0100 0100 0100 0100 0100	0100 0100 0100 0100 0100 0100 0100	0100 0100 0100 0100 0100 0100 0100	0100 0100 0110 0110 0100	0100	0100 0100 0100 0100
EA	000000 000000 000000 000000 000000 00000	000000 000000 000000 000000 000000 00000	000000 000000 000000 000000 000000	0000000		000000
AC AC	000005 000004 000004 000004 000004 000322 001510 001510	000004 000003 000003 000003 001510 004730 004730	000003 000002 000002 000002 004730 011660 011660	000001 000001 000001 000001 000001	O11660 INPUT	000003 000003 000003
MOR	000005 000001 000004 000002 004043 000322 000004 001510	000004 000001 000003 004043 004730 004730	000003 000001 000002 000002 004043 004730 011660	000002 000001 000001 000002 004043	011660 UNIT.	600001 000003 000003 004012
OPERAND	N N N ANSWER RESULT N RESULT JAIL	N 1 2 2 ANSWER RESULT N RESULT JAIL	N 1 N 2 ANSWER RESULT N RESULT JAIL	N 1 2 2 ANSWER RESULT EACHODIAL	RIAL 1/0	NUMBER OF IT M M FACTORIAL
INSTR	LET (IF) MINUS YIELD IS LESS THEN GO LET (IF) TIPRES YIELD GO TO	HET (IF) MINUS MINUS IS LESS THEN GO LET (IF) TIMES YIELD GO TO	LET (IF) MINUS YIELD IS LESS THEN GO LET (IF) TIMES YIELD GO TO	HET (IF) MINUS YIELD IS LESS THEN GO LET (IF)		INPUT/OU YIELD LET (IF) TRANSFOR
SI	JAIL 004032 004033 004034 004035 004035 004037 004041 004041	JAIL 004032 004033 004034 004035 004035 004036 004040	004032 004033 004033 004034 004035 004035 004040 004041	JALL 004032 004033 004034 004035 004035 ANSWER	FACTORIAL OO4005 YIELD	004006 004007 004010 004011

TIME	737.50 742.50 748.75 753.75 761.25 768.75 775.00 781.25	806.25 806.25 870.00 877.50	888.75 895.00 902.50 908.75 913.75	925.00 932.50 938.75 945.00 955.00	961,25 966,25 972,50 977,50 985,00 992,50 998,75 1005,00 1012,50 1012,50 1013,75 1023,75 1023,75 1023,75
SI SI	000000 000000 000000 000000 000000 00000	000000	000000 000000 000000 000000	000000	000000 000000 000000 000000 000000 00000
EAR	000224 000222 000224 000225 000226 000227 000226 000231	000233 000227 000226 000227 000227	000226 000231 000226 000232 000233	000222 000217 000214 000216 000222	000224 000222 000224 000225 000226 000227 000232 000232 000232 000227
×	000000000	00000	00000	0000	0000000000000
SS	000000000000000000000000000000000000000	0000000	000000 000000 000000	000000	000000000000000000000000000000000000000
ρι	888888888	888888	88888 8	8 8888	888888888888888888888888888888888888888
NEW	260224 420222 460224 420225 600226 600226 200226 240231 260226	420233 200227 440226 600227 620230	200226 240231 600226 260232 420233	620222 600217 200214 240216 060222	260224 420222 460224 420225 600225 200226 240231 600226 240231 440233 440226 600227 600227 600227 600227
S	322222222	122222	21 22 22 23 23 23 23 23 23 23 23 23 23 23	21 21 21 21 21 21 21 21 21 21 21 21 21 2	122222222222222
ACDO	0100 0100 0100 0100 0100 0100	0100 0100 0100 0100	0100 0100 0100 0110 0100	0100 0100 0100 0100	0100 0100 0100 0100 0100 0100 0100 010
EA		000000	000000	000000	
AC	000003 000003 000003 000003 000003 000003 000003	000003 0000006 0000006 0000006	000001 000001 000001 000001 000001	0000006 0000006 0000004 0000004	0000004 0000004 0000004 0000004 0000004 000000
MOR	000000 000000 000000 000000 0000003 000000	004043 000003 0000002 000006 004032	0000001 0000001 0000002 004043	004012 000006 000007 004016	000000 004016 000000 0000004 0000004 0000004 0000001 0000003 0000003 0000004 0000004 0000004
OPERAND	O FACTORIAL O ANSWER EQUAL N RESULT N N N	ANSWER RESULT N RESULT JAIL	N 1 N 2 ANSWER RESULT	FACTORIAL N FACTORIAL N FACTORIAL FACTORIAL	O FACTORIAL O ANSWER EQUAL N RESULT N 1 N 2 2 2 2 2 2 8 8 8 8 8 1 1 N N N N N N N N N N N N N
INSTR	IS LESS THEN GO IS EQUAL THEN GC YTELD YIELD LET (IF) MINUS YIELD YIELD LET (IF)	THEN GO LLET (IF) TIMES YIELD GO TO	LET (IF) MINUS YIELD IS LESS THEN GO LET (IF)	GO TO YIELD LET (IF) MINUS TRANSFOR	IS LESS THEN GO IS EQUAL THEN GO YIELD YIELD YIELD LET (IF) MINUS YIELD IS LESS THEN GO LET (IF) THEN GO LET (IF)
IC	FACTORIAL 004024 004025 004025 004027 004030 004031 004033		1032 1033 1034 1035 1036 1036 1043	004044 FACTORIAL 004012 004013 004014 004015	004024 004025 004025 004027 004031 004033 004033 004035 004035 004040 004040

					10
н.					1446,25
TIME	1112.50 1118.75 1126.25 1132.50 1137.50	1207.50 1215.00 1220.00	1226.25 1232.50 1240.00 1246.25 1251.25	1257.50 1262.50 1326.25 1333.75 1340.00 1446.25	1457,50 1457,50
SI	000000 000000 000000 000000 000000	000000	000000	000000	DEVICE 1 000000 000000
EAR	000226 000231 000226 000232 000233	000226 000227 000230	000226 000231 000226 000232 000233	000227 000222 000217 000220 000215	0 000012 0 000000
×	000000	000	00000	00 0000	000
SS	000000	000000	000000	0000000	000000
በ	88888	888	88888	88 8888	88
MEM	200226 240231 600226 260232 420233	440226 600227 620230	200226 240231 600226 260232 420233	200227 620222 440217 600220 200215 640220	160212
o i	22222	222	7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	22 222	ដដ
ACDO	0100 0100 0100 0100	0100 0100 0100	0100 0100 0110 0110	0100 0100 0100 0100 0100	0043)
EV	000000 000000 000000 000000 000000	000000	000000	000000 000000 000000 000000 000000	DATA (000043) 000000 0100 000000 0100
AC	000003 000002 000002 000002 000002	000030	000002 000001 000001 000001	000030 000030 000220 060220 011660	OUTPUT 000043 000043
MOR	000003 000001 000002 000002 004043	000002 000030 004032	000002 000001 000001 000002 004043	000030 004016 000006 000220 011660	O UNIT. CO 400001
OPERAND	N 1 N 2 2 ANSWER RFSHIT	N RESULT JAIL	N 1 N 2 ANSWER	RESULT FACTORIAL M FACTORIAL DENOMINATOR N FACTORIAL DENOMINATOR	*** 400001 IS SENT TO THE I/O U 004022 INPUT/OU NUMBER OF CO 004023 HALT
INSTR	LET (IF) MINUS YIELD IS LESS THEN GO IFFT (IF)	TIMES YIELD GO TO	LET (TF) MINUS YIELD IS LESS THEN GO	LET (IF) GO TO TIMES YIELD LET (IF) OVER	001 IS SEN INPUT/OU HALT
21	JAIL 004032 004033 004034 004035 004036	004040 004041 004042 JAIL	004032 004033 004034 004035	ANSWER 004043 004044 FACTORIAL 004016 004017 004020 004021	*** 4000 004022 004023

RUNNING TIME = .001 SECS
INSTRUCTIONS EXECUTED = 131

TOTAL	8.8	30.00	8.5	38	33,75	162,50	75.00	87.50	8	00.0	88	8	85,00	382,50	0.00	88	8	8	225.00	000	80	00.	8	8,8	88	00.	8.8	8.8	88	8	00	88	0,	88	3.5	88	00
INSTR	6.25	10,00	7.50			6.25	6.25	6.25	6.25	9,0	25.0	• •	5.00	•	6.23	6.25	2.00		•	9 6	• 6	14	•	2°.	88	3,75	٠, ۱	ر د د	26.25		3,75	5.00 2.75	• •		3,75	٠.	3,75
COUNT	00	, m	0	- 0	<u>ښ</u>	26	12	14	0	- - ())	00	17	σ.	m (,		. 0	30	11	4 C	0	0	0.0		0	0 (- -	, 0	0	00	0	0	00	00	0
ŏ							AN	1																į	200									DEC			
VERB	SUBSCRIPT BY	TRANSFORMED BY	EXTENSION IN	TE To av	INPUT/OUTPUT FROM	(F)	ISNT GREATER THAN	LESS THAN	WITH		BY	•	GO TO		IS EQUAL TO	NITH EVERNOTON LITTH		E CYCLED BY		(RETURN FROM)	IK TOTO TOTO TOTO IN			H	MANY ILLEGAL INSTRUCTION	OVERFLOW		POSITIVE	red remains	LF PAKITY UDD	I OVERFLOW	COMPLEMENTED	PAGE	E EXTENSION WITH DEC	NORMALIZED		FALSE
	STEP	TRANS	SAVE	EXECUTE	INPUI	rer (IF SS	IS LE	ANDED	SETS	CYCLED	DOUBLE TET TO	THEN	TIMES	IS EC	ORED		~~	YIELD	02, 05	OVER	EXCLI	RESU	SAVE	****** H A I H	E G		IS P(7 17	RESET	COMP	SET	CLOSE	NORM	OREXIT	IS F